







Index

- 1. MCS PASS | MAHLE CYBER SECURITY PASS
- 2. CYBER SECURITY
- 3. E-SCAN
- 4. ODO-SCAN
- 5. DOIP | DIAGNOSTICS OVER INTERNET PROTOCOL

- 6. DIGITAL ADAS
- 7. START & STOP
- 8. ADJUSTMENTS
- 9. NEW CONTENT ON ALREADY ISSUED SYSTEMS
- 10. UPDATES



MCS Pass



Be prepared for the innovation that facilitates your access to Cyber Security diagnosis.

MCS Pass is a standard way of registering for auto repair users who intend to operate on vehicles protected by Cyber Security.

It is a one-time procedure , for each user and it applies to all brands involved by Cyber Security (current and future).

It is aligned with the requirements of the Manufacturers with whom MAHLE has signed agreements for Cyber Security access.



https://mahlemktg.info/VIDEO_MCS_PASS_BB_EN





marketing.aftermarket@mahle.com

Cyber Security

ALFA ROMEO

GIULIA [2016] (952) STELVIO [2016] (949) TONALE [2022]

AUDI*

A1 [2018] (GB)
A3 [2012-2019] (8V)
A3 [2020] (8Y)
A4 [2015] (8W)
A5 [2016] (F5)
A6 [2011-2018] (4G)
A6 [2017] (4A)
A7 [2017] (4K)
A8 [2017] (4N)
E-TRON GT [2021]
Q2 [2016] (GA)
Q3 [2018] (3B)
Q4 e-tron [2021] (F4)

CUPRA*

Q5 [2017] (BY)

Q8 [2018] (4M)

Q8 E-TRON [2022] (GE) - new

BORN [2021] (K1)

DACIA ***

SANDERO III [2021] (XJF) SPRING [2020] (XBG)

FIAT

500e [2020] (332) 500L [2012] (330) 500X [2015] (334) DOBLO` [2009-2022] (152) DOBLO` CARGO [2009] (263) DUCATO [2022]

JEEP

AVENGER [2022] (J2)
CHEROKEE [2014] (KL)
COMPASS [2016] (MP)
GLADIATOR [2021] (JT)
GRAND CHEROKEE IV [2014-2022] (WK2)
RENEGADE [2014] (BU)

MAN*

TGE [2017]

MERCEDES BENZ

WRANGLER [2017] (JL)

A [2018] (177) AMG GT [2018] (X290) B [2019] (247) C [2014-2021] (205) C [2021] (206) ** CLA [2019] (118) CLS [2017] (257) E [2015] (213-238) EQA [2021] (243) EQB [2021] (243) EQC [2019] (293) EQE [2021] (295) ** EQS [2021] (297) ** EQS SUV [2022] (296) ** EQV [2021] (447) G [2018] (463) GLA [2020] (247) GLB [2020] (247) GLC [2015-2022] (X253)

GLC [2022] (X254) **
GLE [2019] (167)
GLS [2019] (167)
S [2013-2020] (222)
S [2014] (217)
S [2020] (223) **
SL [2020] (232) **
SPRINTER [2018] (907-910)
V [2014] (447)

MITSUBISHI *

OUTLANDER IV [2021] (GM-GN) - new

NISSAN*

JUKE [2020] (F16) QASHQAI [2021] (J12) X-TRAIL [2021] (T33)

RAM

RAM 1500 [2019] (DT)

RENAULT ***

ARKANA[2019](XJL)
CAPTUR II [2020] (XJB)
CLIO V [2019] (XJA)
ESPACE V PH02 [2021] (XFC)
EXPRESS II [2021] (XJK)
KANGOO III [2021] (XFK)
MEGANE IV PH02 [2021] (XFF)
TALISMAN PH02 [2021] (XFD)
ZOE II [2020] (X10)

(*) Manual Cyber Security unlocking

(**) 2° Level Cyber Security

(***) Integrated Cyber Security unlocking

Cyber Security

SKODA*

ENYAQ [2020] (NY)
KAMIQ [2019]
KODIAQ [2017] (NS7, NV7, NS6)
OCTAVIA [2020] (NX)

VOLKSWAGEN*

CCADDY V [2020] (SB)

CARAVELLE T6.1 [2020] (SG)

GOLF VIII [2020] (CD)

ID.3 [2020] (E1)

ID.4 [2020] (E21)

ID.5 [2021] (E39) - new

ID.BUZZ [2022] (EB) - new

MULTIVAN T6.1 [2019-2021] (SG)


TAIGO [2021] (CS)

T-CROSS [2019] (C11)

TIGUAN [2016] (AD-AX)

TIGUAN [2016] (AD-AX)
TOUAREG [2017] (CR)
TRANSPORTER T6.1 [2020] (SG)
T-ROC [2017] (A1-D1)

(*) Manual Cyber Security unlocking
(**) 2° Level Cyber Security



E-SCAN | New

AUDI - Q8 E-TRON [2022] (GE)

MIN/MAX VOLTAGES
OVERALL SOC
OVERALL TEMPERATURE
OVERALL VOLTAGE
SOH

HYUNDAI - IONIQ 5 [2021] (NE)

CELL / BLOCK RESISTANCES
CELL / BLOCK VOLTAGES
MIN/MAX VOLTAGES
OVERALL SOC
OVERALL VOLTAGE
SECTOR TEMPERATURES
SOH

JEEP - AVENGER [2022] (J2)

CELL / BLOCK VOLTAGES
CELL/BLOCK AVERAGE VOLTAGE
MIN/MAX VOLTAGES
OVERALL SOC
OVERALL VOLTAGE
SOH

MERCEDES BENZ - EQA [2021] (243)

CELL / BLOCK VOLTAGES
CELL/BLOCK AVERAGE VOLTAGE
MIN/MAX VOLTAGES
OVERALL TEMPERATURE
OVERALL VOLTAGE
SECTOR TEMPERATURES

MERCEDES BENZ - EQB [2021] (243)

CELL / BLOCK VOLTAGES

CELL/BLOCK AVERAGE VOLTAGE

MIN/MAX VOLTAGES

OVERALL TEMPERATURE

OVERALL VOLTAGE

SECTOR TEMPERATURES

VOLKSWAGEN - ID.5 [2021] (E39)

CELL / BLOCK VOLTAGES
MIN/MAX VOLTAGES
OVERALL SOC
OVERALL TEMPERATURE
OVERALL VOLTAGE
SECTOR TEMPERATURES



ODO-SCAN | New

AUDI

A1 [2018] (GB) Q3 [2018] (3B) Q4 e-tron [2021] (F4)

BMW

2 [2014-2019] (F22-F23)

2 [2021] (G42)

2 Active Tourer [2014-2019] (F45-F46)

4 [2020] (G22-G23-G24-G26-G82)

5 [2010-2017] (F10) 7 [2009-2015] (F01) X1 [2009-2015] (E84)

X5 [2018] (G05) X6 [2014-2019] (F16)

CITROEN

C4 [2020] (C41) C4 SPACETOURER [2018] C5 X [2021] JUMPY [2016] (K0)

DS

DS4 [2021] DS7 [2018] (X74)

FIAT

500X [2015] (334) DOBLO' [2009-2022] (152) FIORINO [2008] (300) TIPO [2015] (356)

FORD

FOCUS [2018] KUGA [2020] PUMA [2020]

JEEP

COMPASS [2016] (MP) RENEGADE [2014] (BU)

MERCEDES BENZ

SL [2022] (232)

OPEL

CORSA F [2020]

PEUGEOT

2008 [2020] 3008 [2016-2024] (P84) 408 [2022] 5008 [2017] (P87) EXPERT [2016] (K0)

PORSCHE

PANAMERA [2016] (971)

SEAT

ARONA [2017] (KJ)
IBIZA [2008-2017] (6J-6P)
IBIZA [2017] (KJ)
LEON [2012-2019] (5F)
LEON [2020] (KL)
TOLEDO [2012-2019] (NH)

SKODA

ENYAQ [2020] (NY)
FABIA [2014-2021] (NJ)
KAMIQ [2019]
KAROQ [2017] (NU)
KODIAQ [2017]
OCTAVIA [2013-2019] (5E)
OCTAVIA [2020] (NX)
RAPID [2012-2019] (NH)
SCALA [2019]
YETI [2009-2017] (5L)

VOLKSWAGEN

CADDY [2015-2020] (SA)
GOLF VII [2012-2019] (5G)
GOLF VII [2012-2019] (5G)
GOLF VIII [2020] (CD)
ID.3 [2020] (E1)
ID.4 [2020] (E21)
ID.BUZZ [2022] (EB)
JETTA VI [2011-2018] (16)
POLO [2014-2018] (6C)
POLO [2018] (AW)
TIGUAN [2016] (AD-AX)

DolP | Diagnostics Over Internet Protocol

JAGUAR - E-PACE [2017] (X540)

EDI (ELECTRONIC DIESEL INJECTION) ADDITIVE DIESEL CONTROL / AD BLUE

EGR VALVE ADAPTATION

INJECTOR CODING

PARTICULATE FILTER SYSTEM

SELF-LEARNING PARAMETERS RESET

THROTTLE VALVE ADAPTATION

JAGUAR - F-PACE [2015] (X761)

ABS

AIR CONDITIONING
AUTOMATIC GEARBOX

DASHBOARD

EDI (ELECTRONIC DIESEL INJECTION)
EFI (ELECTRONIC PETROL INJECTION)

GEAR SELECTION MODULE
PARKING ASSISTANCE SYSTEM

POWERSTEERING SRS (AIRBAG)

ODOMETER READING

ADDITIVE DIESEL CONTROL / AD BLUE AUTOMATIC GEARBOX: OIL LEVEL CHECK

BRAKE PADS REPLACING EGR VALVE ADAPTATION INJECTOR CODING

PARTICULATE FILTER SYSTEM

SELF-LEARNING PARAMETERS RESET

THROTTLE VALVE ADAPTATION

START/STOP

JAGUAR - I-PACE [2018] (X590)

DYNAMIC FRONT CAMERA CALIBRATION (MOVING VEHICLE)

ABS

BATTERY PACK BODY COMPUTER BRAKE ASSIST

CAMERA CONTROL MODULE

CHARGER SYSTEM

DASHBOARD

DCDC CONVERTER

ELECTRIC MOTOR

SRS (AIRBAG)

ODOMETER READING

BRAKE CIRCUIT BLEEDING

BRAKE PADS REPLACING

JAGUAR - XE [2014] (X760)

EDI (ELECTRONIC DIESEL INJECTION)

ADDITIVE DIESEL CONTROL / AD BLUE

EGR VALVE ADAPTATION

INJECTOR CODING

PARTICULATE FILTER SYSTEM

SELF-LEARNING PARAMETERS RESET

THROTTLE VALVE ADAPTATION

JAGUAR - XF [2015] (X260)

EDI (ELECTRONIC DIESEL INJECTION)

ADDITIVE DIESEL CONTROL / AD BLUE

EGR VALVE ADAPTATION

INJECTOR CODING

PARTICULATE FILTER SYSTEM

SELF-LEARNING PARAMETERS RESET

THROTTLE VALVE ADAPTATION

LAND ROVER - DISCOVERY [2016] (L462-LR)

INITIALIZATION OF THE RAIN AND LIGHT SENSOR

ABS

AUTOMATIC GEARBOX

BODY COMPUTER

CHASSIS CONTROL MODULE

DASHBOARD

EDI (ELECTRONIC DIESEL INJECTION)

GEAR SELECTION MODULE

PARKING ASSISTANCE SYSTEM

POWERSTEERING

SRS (AIRBAG)

STEERING ANGLE SENSOR

DolP | Diagnostics Over Internet Protocol

LAND ROVER - DISCOVERY [2016] (L462-LR)

TYRE PRESSURE MONITORING SYSTEM (TPMS)

ODOMETER READING

ADDITIVE DIESEL CONTROL / AD BLUE

BRAKE PADS REPLACING EGR VALVE ADAPTATION ENGINE OIL SERVICE RESET

INITIALIZATION OF THE RAIN AND LIGHT SENSOR

INJECTOR CODING ODOMETER READING

PARTICULATE FILTER SYSTEM

SELF-LEARNING PARAMETERS RESET

SERVICE: RESET OF DIESEL MAINTENANCE INDICATOR SERVICE: RESET OF PETROL MAINTENANCE INDICATOR

STEERING WHEEL ANGLE CALIBRATION

SUSPENSIONS CALIBRATION THROTTLE VALVE ADAPTATION TPMS LEARNING PROCEDURE

LAND ROVER - RANGE [2017] (L560)

ABS

DASHBOARD

EDI (ELECTRONIC DIESEL INJECTION)

ODOMETER READING

ADDITIVE DIESEL CONTROL / AD BLUE

BRAKE PADS REPLACING EGR VALVE ADAPTATION ENGINE OIL SERVICE RESET

INJECTOR CODING

PARTICULATE FILTER SYSTEM

SELF-LEARNING PARAMETERS RESET

SERVICE: RESET OF DIESEL MAINTENANCE INDICATOR
SERVICE: RESET OF PETROL MAINTENANCE INDICATOR

STEERING WHEEL ANGLE CALIBRATION

THROTTLE VALVE ADAPTATION

LAND ROVER - RANGE ROVER EVOQUE [2018] (L551)

ABS

AUTOMATIC GEARBOX

DASHBOARD

EDI (ELECTRONIC DIESEL INJECTION)

GEAR SELECTION MODULE

POWERSTEERING SRS (AIRBAG)

ODOMETER READING

ADDITIVE DIESEL CONTROL / AD BLUE

BRAKE PADS REPLACING
EGR VALVE ADAPTATION
ENGINE OIL SERVICE RESET

INJECTOR CODING

PARTICULATE FILTER SYSTEM

SELF-LEARNING PARAMETERS RESET

SERVICE: RESET OF DIESEL MAINTENANCE INDICATOR SERVICE: RESET OF PETROL MAINTENANCE INDICATOR

STEERING WHEEL ANGLE CALIBRATION

THROTTLE VALVE ADAPTATION

LAND ROVER - RANGE ROVER SPORT [2013] (L494)

ABS

BRAKE PADS REPLACING

LYNK&CO - 01 [2021]

DYNAMIC FRONT CAMERA CALIBRATION (MOVING VEHICLE)
DYNAMIC FRONT RADAR CALIBRATION (MOVING VEHICLE)

INITIALIZATION OF THE RAIN AND LIGHT SENSOR

ABS

AIR CONDITIONING
AUTOMATIC GEARBOX
BATTERY CONTROL SYSTEM

BATTERY PACK
BODY COMPUTER
BRAKE ASSIST

CAMERA CONTROL MODULE

DoIP | Diagnostics Over Internet Protocol

LYNK&CO - 01 [2021]

CHARGER SYSTEM

DASHBOARD

DCDC CONVERTER

DOORS SYSTEM

EFI (ELECTRONIC PETROL INJECTION)

GEAR SELECTION MODULE

LANE CHANGE ASSIST (BLIND SPOT)

LIGHTS SYSTEM

MULTIMEDIA SYSTEMS

PARKING ASSISTANCE SYSTEM

POWERSTEERING

RADAR

SRS (AIRBAG)

STEERING ANGLE SENSOR STEERING CONTROL UNIT CELL / BLOCK VOLTAGES MIN/MAX VOLTAGES

OVERALL SOC

OVERALL VOLTAGE

SECTOR TEMPERATURES

ODOMETER READING

BRAKE CIRCUIT BLEEDING BRAKE PADS REPLACING

CELL / BLOCK VOLTAGES
ENGINE OIL SERVICE RESET

GEAR NEUTRAL POSITION SENSOR ADAPTATION

INITIALIZATION OF THE RAIN AND LIGHT SENSOR

MIN/MAX VOLTAGES

ODOMETER READING

OVERALL SOC

OVERALL VOLTAGE

PARTICULATE FILTER SYSTEM

SECTOR TEMPERATURES

SELF-LEARNING PARAMETERS RESET

SERVICE: RESET OF DIESEL MAINTENANCE INDICATOR SERVICE: RESET OF PETROL MAINTENANCE INDICATOR

TRANSPORT MODE

GEAR NEUTRAL POSITION SENSOR ADAPTATION

MERCEDES BENZ - C [2021] (206)

DYNAMIC FRONT RADAR CALIBRATION (MOVING VEHICLE)

STATIC FRONT CAMERA CALIBRATION (STATIONARY VEHICLE

WITH TARGET)

ABS

AIR CONDITIONING

AUTOMATIC GEARBOX

BODY COMPUTER

CAMERA CONTROL MODULE

CENTRAL CONSOLE

DASHBOARD

DCDC CONVERTER

DOORS SYSTEM

EDI (ELECTRONIC DIESEL INJECTION)

ELECTRONIC IGNITION SWITCH

FUEL SYSTEM

LIGHTS SYSTEM

PARKING ASSISTANCE SYSTEM

POWERSTEERING

POWERTRAIN CONTROL UNIT

RADAR

SRS (AIRBAG)

TYRE PRESSURE MONITORING SYSTEM (TPMS)

MIN/MAX VOLTAGES

SECTOR TEMPERATURES

ODOMETER READING

DoIP | Diagnostics Over Internet Protocol

MERCEDES BENZ - C [2021] (206)

ADDITIVE DIESEL CONTROL / AD BLUE

BRAKE PADS REPLACING EGR VALVE ADAPTATION INJECTOR CODING

SELF-LEARNING PARAMETERS RESET

SERVICE: RESET OF DIESEL MAINTENANCE INDICATOR
SERVICE: RESET OF PETROL MAINTENANCE INDICATOR

STEERING WHEEL ANGLE CALIBRATION

THROTTLE VALVE ADAPTATION
TPMS LEARNING PROCEDURE

MERCEDES BENZ - EQE [2021] (295)

DYNAMIC FRONT RADAR CALIBRATION (MOVING VEHICLE)

ABS

CAMERA CONTROL MODULE

DASHBOARD DOORS SYSTEM

ELECTRONIC IGNITION SWITCH

LIGHTS SYSTEM

PARKING ASSISTANCE SYSTEM

POWERSTEERING

RADAR SRS (AIRBAG)

TYRE PRESSURE MONITORING SYSTEM (TPMS)

ODOMETER READING BRAKE PADS REPLACING

SERVICE: RESET OF DIESEL MAINTENANCE INDICATOR
SERVICE: RESET OF PETROL MAINTENANCE INDICATOR

STEERING WHEEL ANGLE CALIBRATION

TPMS LEARNING PROCEDURE

MERCEDES BENZ - EQS [2021] (297)

DYNAMIC FRONT RADAR CALIBRATION (MOVING VEHICLE)

ABS

AIR CONDITIONING BODY COMPUTER

CAMERA CONTROL MODULE

CENTRAL CONSOLE

DASHBOARD
DOORS SYSTEM

ELECTRONIC IGNITION SWITCH

LIGHTS SYSTEM

PARKING ASSISTANCE SYSTEM

POWERSTEERING

RADAR

SRS (AIRBAG)

TYRE PRESSURE MONITORING SYSTEM (TPMS)

ODOMETER READING BRAKE PADS REPLACING

SERVICE: RESET OF DIESEL MAINTENANCE INDICATOR SERVICE: RESET OF PETROL MAINTENANCE INDICATOR

STEERING WHEEL ANGLE CALIBRATION

TPMS LEARNING PROCEDURE

MERCEDES BENZ - EQS [2022] (296)

ABS

AIR CONDITIONING BODY COMPUTER

CAMERA CONTROL MODULE

CENTRAL CONSOLE

DASHBOARD

DOORS SYSTEM

ELECTRONIC IGNITION SWITCH

LIGHTS SYSTEM

PARKING ASSISTANCE SYSTEM

POWERSTEERING

RADAR

SRS (AIRBAG)

TYRE PRESSURE MONITORING SYSTEM (TPMS)

ODOMETER READING

BRAKE PADS REPLACING

SERVICE: RESET OF DIESEL MAINTENANCE INDICATOR SERVICE: RESET OF PETROL MAINTENANCE INDICATOR

STEERING WHEEL ANGLE CALIBRATION

TPMS LEARNING PROCEDURE

DoIP | Diagnostics Over Internet Protocol

MERCEDES BENZ - GLC [2022] (X254)

DYNAMIC FRONT RADAR CALIBRATION (MOVING VEHICLE)
STATIC FRONT CAMERA CALIBRATION (STATIONARY VEHICLE
WITH TARGET)

ABS

AIR CONDITIONING
AUTOMATIC GEARBOX
CAMERA CONTROL MODULE

DASHBOARD
DCDC CONVERTER
DOORS SYSTEM

EDI (ELECTRONIC DIESEL INJECTION)
ELECTRONIC IGNITION SWITCH

FUEL SYSTEM LIGHTS SYSTEM

PARKING ASSISTANCE SYSTEM

POWERSTEERING

POWERTRAIN CONTROL UNIT

RADAR

SRS (AIRBAG)

TYRE PRESSURE MONITORING SYSTEM (TPMS)

MIN/MAX VOLTAGES
SECTOR TEMPERATURES
ODOMETER READING

ADDITIVE DIESEL CONTROL / AD BLUE

BRAKE PADS REPLACING EGR VALVE ADAPTATION INJECTOR CODING

SELF-LEARNING PARAMETERS RESET

SERVICE: RESET OF DIESEL MAINTENANCE INDICATOR SERVICE: RESET OF PETROL MAINTENANCE INDICATOR

STEERING WHEEL ANGLE CALIBRATION

THROTTLE VALVE ADAPTATION
TPMS LEARNING PROCEDURE

MERCEDES BENZ - S [2020] (223)

DYNAMIC FRONT RADAR CALIBRATION (MOVING VEHICLE)
STATIC FRONT CAMERA CALIBRATION (STATIONARY VEHICLE
WITH TARGET)

ABS

AIR CONDITIONING AUTOMATIC GEARBOX BODY COMPUTER

CAMERA CONTROL MODULE

DASHBOARD
DCDC CONVERTER
DOORS SYSTEM

EDI (ELECTRONIC DIESEL INJECTION)
ELECTRONIC IGNITION SWITCH

FUEL SYSTEM LIGHTS SYSTEM

PARKING ASSISTANCE SYSTEM

POWERSTEERING

POWERTRAIN CONTROL UNIT

RADAR SRS (AIRBAG)

TYRE PRESSURE MONITORING SYSTEM (TPMS)

MIN/MAX VOLTAGES
SECTOR TEMPERATURES
ODOMETER READING

ADDITIVE DIESEL CONTROL / AD BLUE

BRAKE PADS REPLACING EGR VALVE ADAPTATION INJECTOR CODING

SELF-LEARNING PARAMETERS RESET

SERVICE: RESET OF DIESEL MAINTENANCE INDICATOR SERVICE: RESET OF PETROL MAINTENANCE INDICATOR

STEERING WHEEL ANGLE CALIBRATION

THROTTLE VALVE ADAPTATION
TPMS LEARNING PROCEDURE

MERCEDES BENZ - SL [2022] (232)

DYNAMIC FRONT RADAR CALIBRATION (MOVING VEHICLE)

ABS

AIR CONDITIONING
AUTOMATIC GEARBOX

DolP | Diagnostics Over Internet Protocol

MERCEDES BENZ - SL [2022] (232)

BODY COMPUTER

CAMERA CONTROL MODULE

CENTRAL CONSOLE

DASHBOARD

DCDC CONVERTER

DOORS SYSTEM

ELECTRONIC IGNITION SWITCH

FUEL SYSTEM

LIGHTS SYSTEM

PARKING ASSISTANCE SYSTEM

POWERSTEERING

POWERTRAIN CONTROL UNIT

RADAR

SRS (AIRBAG)

TYRE PRESSURE MONITORING SYSTEM (TPMS)

MIN/MAX VOLTAGES

SECTOR TEMPERATURES

ODOMETER READING

BRAKE PADS REPLACING

SERVICE: RESET OF DIESEL MAINTENANCE INDICATOR

SERVICE: RESET OF PETROL MAINTENANCE INDICATOR

STEERING WHEEL ANGLE CALIBRATION

TPMS LEARNING PROCEDURE

POLESTAR - 2 [2019] (P)

ABS

AIR CONDITIONING

ANTI-THEFT SYSTEM

BATTERY CONTROL SYSTEM

BATTERY PACK

BODY COMPUTER

CHARGER SYSTEM

COMMUNICATION INTERFACE

DASHBOARD

ELECTRIC MOTOR

GEAR SELECTION MODULE

POWERSTEERING

SRS (AIRBAG)

STEERING ANGLE SENSOR

STEERING CONTROL UNIT

STEERING LOCK

CELL / BLOCK VOLTAGES

OVERALL SOC

OVERALL VOLTAGE

CELL / BLOCK VOLTAGES

OVERALL SOC

OVERALL VOLTAGE

TRACTION BATTERY CURRENT TRACTION BATTERY VOLTAGE

DoIP Smart

- Adapter to be connected between Connex / TechPRO VCI and the vehicle, translates the communication into the new DoIP protocol.
- Connex / TechPRO VCI automatically detects the presence / absence of the DoIP Smart and prompts the user to remove / insert it when requested / not required.
- The CAN lines on pins 6 14 pass through the adapter. Standard OBD diagnostics (on CAN BUS) is also supported with DoIP Smart installed.
- It complies with the ISO 13400 standard and supports both market standards with automatic identification of the version present on the vehicle.



CONNEX Digital ADAS

DYNAMIC FRONT RADAR

CALIBRATION (moving vehicle)

CITROEN

C4 X [2022] (BD_, BE_, BF_) C5 X [2021] (ND_, NC_)

DS

DS4 [2021] (F_, FB_, F3_)

JAGUAR

F-PACE [2015] (X761)

JEEP

AVENGER [2022] (J2)

OPEL

ASTRA L [2021] (O5)

PEUGEOT

308 [2021] (P5)

VAUXHALL

ASTRA L [2021] (O5)

DYNAMIC CALIBRATION OF LANE CHANGE ASSIST SYSTEM (blind spot)

DS

DS4 [2021] (F_, FB_, F3_)

DYNAMIC FRONT CAMERA

CALIBRATION (moving vehicle)

JAGUAR

I-PACE [2018] (X590)

STATIC FRONT RADAR

CALIBRATION (stationary vehicle with corner reflector)

KIA

STONIC [2017] (YB)

STATIC FRONT RADAR

CALIBRATION (stationary vehicle with mirror)

PORSCHE

911 [2011-2018] (991) BOXSTER [2012-2015] (981) CAYMAN [2013-2016] (981)

SKODA

ENYAQ [2020] (NY)

STATIC 360° CAMERA CALIBRATION

NISSAN

JUKE [2010-2019] (F15)

DYNAMIC FRONT RADAR

CALIBRATION(stationary vehicle

with target)

PORSCHE

BOXSTER [2012-2015] (981) BOXSTER [2016] (982) CAYMAN [2013-2016] (981) CAYMAN [2016] (982)

STATIC REAR CAMERA CALIBRATION

AUDI

Q4 e-tron [2021] (F4)

VOLKSWAGEN

ID.BUZZ [2022] (EB)



Start & Stop

AUDI - A3 [2020] (8Y)

GEAR NEUTRAL POSITION SENSOR ADAPTATION START/STOP

AUDI - Q2 [2016] (GA)

GEAR NEUTRAL POSITION SENSOR ADAPTATION START/STOP START/STOP FUNCTION ACTIVATION AND DEACTIVATION

AUDI - Q7 [2015-2020] (4M)

START/STOP

AUDI - Q8 [2018] (4M)

START/STOP

AUDI - Q8 E-TRON [2022] (GE)

BATTERY REPLACEMENT
START/STOP
START/STOP FUNCTION ACTIVATION AND DEACTIVATION

BMW - 1 [2011-2019] (F20)

START/STOP FUNCTION ACTIVATION AND DEACTIVATION

BMW - 2 [2014-2019] (F22-F23)

START/STOP FUNCTION ACTIVATION AND DEACTIVATION

BMW - 3 [2011-2019] (F30)

START/STOP FUNCTION ACTIVATION AND DEACTIVATION

BMW - 3 [2018] (G20)

START/STOP FUNCTION ACTIVATION AND DEACTIVATION

BMW - 4 [2013] (F32)

START/STOP FUNCTION ACTIVATION AND DEACTIVATION

BMW - 5 [2017] (G30)

START/STOP FUNCTION ACTIVATION AND DEACTIVATION

BMW - 6 [2017] (G32)

START/STOP FUNCTION ACTIVATION AND DEACTIVATION

BMW - 7 [2015-2022] (G11)

START/STOP FUNCTION ACTIVATION AND DEACTIVATION

BMW - X3 [2017] (G01)

START/STOP FUNCTION ACTIVATION AND DEACTIVATION

FIAT - 500 [2007] (312)

GEAR NEUTRAL POSITION SENSOR ADAPTATION START/STOP

FIAT - TIPO [2015] (356)

GEAR NEUTRAL POSITION SENSOR ADAPTATION

FORD - TOURNEO CONNECT [2022]

START/STOP

KIA - SPORTAGE [2021] (NQ)

START/STOP

MERCEDES BENZ - SLC [2016-2017] (172)

GEAR NEUTRAL POSITION SENSOR ADAPTATION START/STOP

MERCEDES BENZ - V [2014] (447)

BATTERY REPLACEMENT

MINI - COUNTRYMAN [2016] (F60)

BATTERY REPLACEMENT

START/STOP FUNCTION ACTIVATION AND DEACTIVATION

Start & Stop

NISSAN - MICRA [2017] (K14)

START/STOP

OPEL - CORSA E [2014-2019]

GEAR NEUTRAL POSITION SENSOR ADAPTATION START/STOP

OPEL - MOKKA [2012-2020] (J13)

GEAR NEUTRAL POSITION SENSOR ADAPTATION START/STOP

SEAT - LEON [2020] (KL)

GEAR NEUTRAL POSITION SENSOR ADAPTATION START/STOP

VAUXHALL - CORSA E [2014-2019]

GEAR NEUTRAL POSITION SENSOR ADAPTATION START/STOP

VOLKSWAGEN - CADDY V [2020] (SB)

GEAR NEUTRAL POSITION SENSOR ADAPTATION START/STOP

VOLKSWAGEN - GOLF VIII [2020] (CD)

GEAR NEUTRAL POSITION SENSOR ADAPTATION START/STOP

VOLVO - S60 [2010-2018] (134)

GEAR NEUTRAL POSITION SENSOR ADAPTATION START/STOP

VOLVO - S60 [2018] (224)

START/STOP

VOLVO - S90 [2016] (234)

START/STOP

VOLVO - V60 [2010-2018] (155, 157)

GEAR NEUTRAL POSITION SENSOR ADAPTATION START/STOP

VOLVO - V60 [2018] (225, 227)

GEAR NEUTRAL POSITION SENSOR ADAPTATION START/STOP

VOLVO - V90 [2016] (235, 236)

GEAR NEUTRAL POSITION SENSOR ADAPTATION START/STOP

VOLVO - XC40 [2017] (536)

GEAR NEUTRAL POSITION SENSOR ADAPTATION START/STOP

VOLVO - XC60 [2008-2017] (156)

GEAR NEUTRAL POSITION SENSOR ADAPTATION START/STOP

VOLVO - XC60 [2017] (246)

GEAR NEUTRAL POSITION SENSOR ADAPTATION START/STOP

VOLVO - XC90 [2014] (256)

START/STOP

AUDI - A3 [2020] (8Y)

AUTOMATIC GEARBOX: OIL LEVEL CHECK
GEAR NEUTRAL POSITION SENSOR ADAPTATION
INJECTOR CODING
SELF-LEARNING PARAMETERS RESET
THROTTLE VALVE ADAPTATION

AUDI - Q2 [2016] (GA)

GEAR NEUTRAL POSITION SENSOR ADAPTATION INJECTOR CODING
SELF-LEARNING PARAMETERS RESET
THROTTLE VALVE ADAPTATION

AUDI - Q3 [2018] (3B)

AUTOMATIC GEARBOX: OIL LEVEL CHECK

AUDI - Q7 [2015-2020] (4M)

ADDITIVE DIESEL CONTROL / AD BLUE EGR VALVE ADAPTATION INJECTOR CODING PARTICULATE FILTER SYSTEM SELF-LEARNING PARAMETERS RESET THROTTLE VALVE ADAPTATION

AUDI - Q8 [2018] (4M)

ADDITIVE DIESEL CONTROL / AD BLUE EGR VALVE ADAPTATION INJECTOR CODING PARTICULATE FILTER SYSTEM SELF-LEARNING PARAMETERS RESET THROTTLE VALVE ADAPTATION

AUDI - Q8 E-TRON [2022] (GE)

BATTERY REPLACEMENT
BRAKE CIRCUIT BLEEDING
BRAKE PADS REPLACING
HEADLIGHT ADJUSTMENT
POWERWINDOWS INITIALIZING

SERVICE: RESET OF DIESEL MAINTENANCE INDICATOR SERVICE: RESET OF PETROL MAINTENANCE INDICATOR

SERVICE: SETTING DATA SUSPENSIONS CALIBRATION TRANSPORT MODE

BMW - 1 [2011-2019] (F20)

SELF-LEARNING PARAMETERS RESET THROTTLE VALVE ADAPTATION

BMW - 2 [2014-2019] (F22-F23)

EGR VALVE ADAPTATION
IMMOBILIZER INJECTION ALIGNMENT
INJECTOR CODING
PARTICULATE FILTER SYSTEM
SELF-LEARNING PARAMETERS RESET
THROTTLE VALVE ADAPTATION

BMW - 3 [2011-2019] (F30)

SELF-LEARNING PARAMETERS RESET THROTTLE VALVE ADAPTATION

BMW - 3 [2018] (G20)

SELF-LEARNING PARAMETERS RESET THROTTLE VALVE ADAPTATION

BMW - 4 [2013] (F32)

SELF-LEARNING PARAMETERS RESET THROTTLE VALVE ADAPTATION

BMW - 5 [2017] (G30)

SELF-LEARNING PARAMETERS RESET THROTTLE VALVE ADAPTATION

BMW - 6 [2017] (G32)

SELF-LEARNING PARAMETERS RESET THROTTLE VALVE ADAPTATION

BMW - 7 [2015-2022] (G11)

SELF-LEARNING PARAMETERS RESET THROTTLE VALVE ADAPTATION

BMW - X3 [2017] (G01)

SELF-LEARNING PARAMETERS RESET THROTTLE VALVE ADAPTATION

CUPRA - LEON [2020] (KL)

AUTOMATIC GEARBOX: OIL LEVEL CHECK

DS - DS4 [2021] (F_, FB_, F3_)

POWERWINDOWS INITIALIZING

SERVICE: RESET OF DIESEL MAINTENANCE INDICATOR

FIAT - 500 [2007] (312)

ADDITIVE DIESEL CONTROL / AD BLUE

EGR VALVE ADAPTATION
ENGINE OIL SERVICE RESET

GEAR NEUTRAL POSITION SENSOR ADAPTATION

INJECTOR CODING

PARTICULATE FILTER SYSTEM

SELF-LEARNING PARAMETERS RESET

SERVICE: RESET OF DIESEL MAINTENANCE INDICATOR

THROTTLE VALVE ADAPTATION

FIAT - TIPO [2015] (356)

ENGINE OIL SERVICE RESET

GEAR NEUTRAL POSITION SENSOR ADAPTATION

INJECTOR CODING

PARTICULATE FILTER SYSTEM

SELF-LEARNING PARAMETERS RESET

THROTTLE VALVE ADAPTATION

FORD - TOURNEO CONNECT [2022]

ADDITIVE DIESEL CONTROL / AD BLUE

EGR VALVE ADAPTATION

INJECTOR CODING

PARTICULATE FILTER SYSTEM

POWERWINDOWS INITIALIZING

SELF-LEARNING PARAMETERS RESET

SERVICE: RESET OF CNG MAINTENANCE INDICATOR
SERVICE: RESET OF DIESEL MAINTENANCE INDICATOR

SERVICE: RESET OF PETROL MAINTENANCE INDICATOR

SERVICE: SETTING DATA

STEERING WHEEL ANGLE CALIBRATION

THROTTLE VALVE ADAPTATION

TRANSPORT MODE

JAGUAR - I-PACE [2018] (X590)

BRAKE CIRCUIT BLEEDING BRAKE PADS REPLACING

JEEP - RENEGADE [2014] (BU)

ADDITIVE DIESEL CONTROL / AD BLUE

EGR VALVE ADAPTATION

ENGINE OIL SERVICE RESET

INJECTOR CODING

PARTICULATE FILTER SYSTEM

SELF-LEARNING PARAMETERS RESET

THROTTLE VALVE ADAPTATION

KIA - SPORTAGE [2021] (NQ)

PARTICULATE FILTER SYSTEM

SELF-LEARNING PARAMETERS RESET

MERCEDES BENZ - E [2015] (213-238)

ADDITIVE DIESEL CONTROL / AD BLUE

EGR VALVE ADAPTATION

INJECTOR CODING

PARTICULATE FILTER SYSTEM

SELF-LEARNING PARAMETERS RESET

THROTTLE VALVE ADAPTATION

MERCEDES BENZ - SLC [2016-2017] (172)

ADDITIVE DIESEL CONTROL / AD BLUE

GEAR NEUTRAL POSITION SENSOR ADAPTATION

INJECTOR CODING

PARTICULATE FILTER SYSTEM

SELF-LEARNING PARAMETERS RESET

SERVICE

THROTTLE VALVE ADAPTATION

MERCEDES BENZ - V [2014] (447)

BATTERY REPLACEMENT
POWERWINDOWS INITIALIZING
TRANSPORT MODE

MINI - COUNTRYMAN [2016] (F60)

ADDITIVE DIESEL CONTROL / AD BLUE
BATTERY REPLACEMENT
EGR VALVE ADAPTATION
INJECTOR CODING
PARTICULATE FILTER SYSTEM
SELF-LEARNING PARAMETERS RESET

MINI - MINI [2006-2013] (R56)

EGR VALVE ADAPTATION
INJECTOR CODING
PARTICULATE FILTER SYSTEM
SELF-LEARNING PARAMETERS RESET

MITSUBISHI - ECLIPSE CROSS [2018] (GK)

SERVICE: MANUAL RESET OF THE MAINTENANCE INDICATOR

MITSUBISHI - MIRAGE [2012]

SELF-LEARNING PARAMETERS RESET

MITSUBISHI - SPACE STAR [2013]

SELF-LEARNING PARAMETERS RESET

NISSAN - JUKE [2020] (F16)

BRAKE PADS REPLACING
SELF-LEARNING PARAMETERS RESET
STEERING WHEEL ANGLE CALIBRATION

NISSAN - MICRA [2017] (K14)

PARTICULATE FILTER SYSTEM
SELF-LEARNING PARAMETERS RESET
THROTTLE VALVE ADAPTATION

NISSAN - X-TRAIL [2021] (T33)

BRAKE PADS REPLACING
STEERING WHEEL ANGLE CALIBRATION

OPEL - CORSA E [2014-2019]

ENGINE OIL SERVICE RESET
GEAR NEUTRAL POSITION SENSOR ADAPTATION
SELF-LEARNING PARAMETERS RESET
THROTTLE VALVE ADAPTATION

OPEL - MOKKA [2012-2020] (J13)

ADDITIVE DIESEL CONTROL / AD BLUE
ENGINE OIL SERVICE RESET
GEAR NEUTRAL POSITION SENSOR ADAPTATION
INJECTOR CODING
PARTICULATE FILTER SYSTEM
SELF-LEARNING PARAMETERS RESET

PEUGEOT - RCZ [2010] (T75)

ADDITIVE DIESEL CONTROL / AD BLUE
EGR VALVE ADAPTATION
INJECTOR CODING
PARTICULATE FILTER SYSTEM
REPLACEMENT OF ACCESSORIES BELT
SELF-LEARNING PARAMETERS RESET
THROTTLE VALVE ADAPTATION

PORSCHE - MACAN [2013] (95B)

HEADLIGHT ADJUSTMENT
PARTICULATE FILTER SYSTEM
SELF-LEARNING PARAMETERS RESET
THROTTLE VALVE ADAPTATION

PORSCHE - TAYCAN [2019] (Y1A)

POWERWINDOWS INITIALIZING

SEAT - LEON [2020] (KL)

AUTOMATIC GEARBOX: OIL LEVEL CHECK
GEAR NEUTRAL POSITION SENSOR ADAPTATION
INJECTOR CODING
SELF-LEARNING PARAMETERS RESET
THROTTLE VALVE ADAPTATION

SKODA - SUPERB [2015] (3V)

AUTOMATIC GEARBOX: OIL LEVEL CHECK TESLA - MODEL X [2015] (5YJX) BRAKE PADS REPLACING

TOYOTA - CAMRY [2017] (V7-VA7-VH7)

PARTICULATE FILTER SYSTEM
SELF-LEARNING PARAMETERS RESET

TOYOTA - HIGHLANDER [2019] (U7)

PARTICULATE FILTER SYSTEM
SELF-LEARNING PARAMETERS RESET

VAUXHALL - CORSA E [2014-2019]

ENGINE OIL SERVICE RESET
GEAR NEUTRAL POSITION SENSOR ADAPTATION
SELF-LEARNING PARAMETERS RESET
THROTTLE VALVE ADAPTATION

VOLKSWAGEN - CADDY V [2020] (SB)

GEAR NEUTRAL POSITION SENSOR ADAPTATION INJECTOR CODING POWERWINDOWS INITIALIZING SELF-LEARNING PARAMETERS RESET THROTTLE VALVE ADAPTATION

VOLKSWAGEN - GOLF VII [2012-2019] (5G)

AUTOMATIC GEARBOX: OIL LEVEL CHECK

VOLKSWAGEN - GOLF VIII [2020] (CD)

AUTOMATIC GEARBOX: OIL LEVEL CHECK
GEAR NEUTRAL POSITION SENSOR ADAPTATION
INJECTOR CODING
SELF-LEARNING PARAMETERS RESET
THROTTLE VALVE ADAPTATION

VOLKSWAGEN - ID.5 [2021] (E39)

BRAKE CIRCUIT BLEEDING
BRAKE PADS REPLACING
POWERWINDOWS INITIALIZING
SERVICE
SERVICE: SETTING DATA
STEERING WHEEL ANGLE CALIBRATION
TIRE SIZES PROGRAMMING

VOLKSWAGEN - PASSAT [2014] (3G)

AUTOMATIC GEARBOX: OIL LEVEL CHECK

VOLVO - S60 [2010-2018] (134)

ADDITIVE DIESEL CONTROL / AD BLUE
EGR VALVE ADAPTATION
ENGINE OIL SERVICE RESET
GEAR NEUTRAL POSITION SENSOR ADAPTATION
INJECTOR CODING
PARTICULATE FILTER SYSTEM
SELF-LEARNING PARAMETERS RESET
THROTTLE VALVE ADAPTATION

VOLVO - S60 [2018] (224)

ENGINE OIL SERVICE RESET
PARTICULATE FILTER SYSTEM
SELF-LEARNING PARAMETERS RESET
THROTTLE VALVE ADAPTATION

VOLVO - S90 [2016] (234)

ENGINE OIL SERVICE RESET
PARTICULATE FILTER SYSTEM
SELF-LEARNING PARAMETERS RESET
THROTTLE VALVE ADAPTATION

VOLVO - V60 [2010-2018] (155, 157)

ADDITIVE DIESEL CONTROL / AD BLUE
EGR VALVE ADAPTATION
ENGINE OIL SERVICE RESET
GEAR NEUTRAL POSITION SENSOR ADAPTATION
INJECTOR CODING
PARTICULATE FILTER SYSTEM
SELF-LEARNING PARAMETERS RESET

VOLVO - V60 [2018] (225, 227)

THROTTLE VALVE ADAPTATION

ADDITIVE DIESEL CONTROL / AD BLUE
EGR VALVE ADAPTATION
ENGINE OIL SERVICE RESET
GEAR NEUTRAL POSITION SENSOR ADAPTATION
INJECTOR CODING
PARTICULATE FILTER SYSTEM
SELF-LEARNING PARAMETERS RESET
THROTTLE VALVE ADAPTATION

VOLVO - V90 [2016] (235, 236)

ADDITIVE DIESEL CONTROL / AD BLUE
EGR VALVE ADAPTATION
ENGINE OIL SERVICE RESET
GEAR NEUTRAL POSITION SENSOR ADAPTATION
INJECTOR CODING
PARTICULATE FILTER SYSTEM
SELF-LEARNING PARAMETERS RESET
THROTTLE VALVE ADAPTATION

VOLVO - XC40 [2017] (536)

ENGINE OIL SERVICE RESET

GEAR NEUTRAL POSITION SENSOR ADAPTATION
INJECTOR CODING

PARTICULATE FILTER SYSTEM
SELF-LEARNING PARAMETERS RESET

VOLVO - XC60 [2008-2017] (156)

ADDITIVE DIESEL CONTROL / AD BLUE
EGR VALVE ADAPTATION
ENGINE OIL SERVICE RESET
GEAR NEUTRAL POSITION SENSOR ADAPTATION
INJECTOR CODING
PARTICULATE FILTER SYSTEM
SELF-LEARNING PARAMETERS RESET
THROTTLE VALVE ADAPTATION

VOLVO - XC60 [2017] (246)

ADDITIVE DIESEL CONTROL / AD BLUE
EGR VALVE ADAPTATION
ENGINE OIL SERVICE RESET
GEAR NEUTRAL POSITION SENSOR ADAPTATION
INJECTOR CODING
PARTICULATE FILTER SYSTEM
SELF-LEARNING PARAMETERS RESET
SERVICE: RESET OF DIESEL MAINTENANCE INDICATOR
THROTTLE VALVE ADAPTATION

VOLVO - XC90 [2014] (256)

ENGINE OIL SERVICE RESET
PARTICULATE FILTER SYSTEM
SELF-LEARNING PARAMETERS RESET
THROTTLE VALVE ADAPTATION

AUDI - A3 [2012-2019] (8V)

Erase counter for start/stop processes

Oil pressure reservoir emptying Installation information adaptation

Transmission hydraulic pump: basic setting

Transmission: basic setting

Gear actuator and dual clutch: basic setting Gear actuator: adaptation values reset Start double clutch fast adaptation Clutch: adaptation values reset

Clutch characteristic curve: adaptation values reset Disengagement clutch: adaptation values reset

Clutch 2: adaptation values reset
Set gearbox mileage to vehicle mileage

Gearbox mileage reset Set clutch mileage to zero

Selector lever: engagement percentages per position reset

Disengagement clutch: basic setting

Disengagement clutch: characteristic curve reset

Oil pressure reservoir filling Check transmission fluid level Transmission fluid emptying Transmission fluid filling

Clutch 1: adaptation values reset

AUDI - A3 [2020] (8Y)

Fuel pump EGR valve 1 Radiator shutters

Reducing agent (AdBlue) heater Reducing agent (AdBlue) heater 2 Coolant pump for intercooler Radiator 1 fan command Preheating glow 1 control unit

Exhaust flap EGR valve 2 Compression test

Particulate filter forced regeneration (moving vehicle)
Particulate filter forced regeneration (stationary vehicle)

CAN communication monitoring reset

Test of disassembled turbocharger actuator

Fuel high pressure system: leakage measuring point

Switchable coolant pump

Control deviation test of exhaust gas recirculation system

Lambda probe test

Air mass flow meter plausibility test

Automatic glow time control unit test

Turbocharger Test Fuel circuit bleeding

Reset reducing agent (AdBlue) lock

Manual test on exhaust flap
Charge pressure actuator test

Automatic test of low pressure EGR valve

Radiator shutters adaptation

Fuel high pressure system: engine start leak test

Reducing agent (AdBlue) duct emptying

Catalytic converter aging reset

Adaptation of correction angle of camshaft position detection:

angle sensor error (outlet side)

Adaptation of correction angle of camshaft position detection:

angle sensor error (inlet side)

Oil pump pressure level change-over test

Fuel tank emptying

Adaptation of correction angle of camshaft position detection:

phonic wheel angle sensor error (inlet side)

Fuel system flow rate test

Reducing agent system quality sensor adaptation

Reducing agent quality test

Reducing agent (AdBlue) metering quantity test: injector 1

Reduction agent (AdBlue) system complete test

Reducing agent (AdBlue) metering quantity test: injector 2

Brake roller test operating mode

Start/Stop function

Exhaust Gas Recirculation valve (EGR) test Setting of soot mass value in anti particulate filter

Adaptation of correction angle of camshaft position detection:

phonic wheel angle sensor error (outlet side)

AUDI - Q4 e-tron [2021] (F4)

Drive shaft load counter: reset
Production mode deactivation
Adaptation values reset

Saving of ECU coding on file
Writing of ECU coding from file
Delay management: rear camera
Text display on dashboard

Brake lights

Brake roller test operating mode: deactivation

Brake circuit bleeding

ECU coding

Electro-mechanical parking brake function test

Hydraulic brake assistant

Hydraulic pump

Basic setting for brake pressure sensor

Straight brake stabilization

Hydraulic test

Tire pressure monitoring system: factory setting reset

Overboost in brake system

Brake roller test operating mode: activation

Parking brake pads replacement: open brake clamps

Parking brake pads replacement: close brake clamps

Brake pre-filling

Delay management: multiple collision brake Delay management: parking assistant

Basic setting of ESP sensors

Delay management: emergency assistant

Delay management: stopping distance reduction

Delay management: rear cross traffic assistant

Delay management: trailer maneuvering assistant

Delay management: pedestrian protection

ABS in lower speed range Hydraulic valves check

Parking brake actuator: opening Parking brake actuator: closing Brake roller test operating mode

Brake roller test operating mode Resetting of all adaptations Delay management: ACC High voltage battery: coolant valve 1 High voltage battery: coolant pump High voltage battery: coolant valve 2

High voltage battery: heater

Serial number of high-voltage / hybrid battery

ZSB part number
Brake light switch
Brakes test switch
Brake pedal

All adaptation values reset

Leak test

Brake pedal position sensor basic setting

Brake booster bleeding Sluggishness test Radiator shutters Coolant pump Radiator fan 1

Cooling system bleeding

Drive type reset
Charging socket: flap
Charging socket: plug
Locking cycles counter reset

High-voltage system: lock release after crash

Hardware in loop mode

Battery charger A connector: number of successful charge plug

lockings

Battery charger A connector cover: number of lockings Battery charger A connector: connections number Battery charger A connector: lockings number

Front left belt pretensioner Front right belt pretensioner

Crash severity management: front, driver side
Crash severity management: front, passenger side
Crash severity management: lateral, passenger side
Crash severity management: rear, passenger side
Crash severity management: pedestrian protection

Vehicle conditioning Crash-active head restraint Passenger knees airbag

AUDI - Q4 e-tron [2021] (F4)

Pedestrian crash sensor

Driver Airbag

Crash severity management: rear, driver side Crash severity management: lateral, driver side

Crash severity management: rollover
Rear driver side seat belt pretensioner
Rear passenger side seat belt pretensioner
Igniter for deactivation of A/C system 1

Warning messages

Passenger airbag deactivation warning lamp (if present)

Driver knees airbag

Belt pretensioner basic setting Assistance system monitoring Front passenger interaction airbag

Passenger airbag

Front driver side lateral airbag
Front passenger side pretensioner
High voltage battery 3 disconnect igniter
Occupied seat recognition, driver side

3rd row center pretensioner

Igniter for deactivation of A/C system 2

Occupied seat recognition, front passenger side

Active head restraint activations reset Passenger side active headrest Rear driver side lateral airbag Battery Disconnect Igniter

Rear passenger interaction airbag
High voltage battery 2 disconnect igniter
DC/DC converter disconnect igniter

Rollover protection system
Rear driver side head airbag
Rear passenger side head airbag
Pre-crash system: rear left belt feeder
Pre-crash system: rear right belt feeder

Driver side active headrest

Rear central seat belt pretensioner squib

2nd battery disconnect igniter

Pre-crash system: rear seatbelt pretensioner - left side

Battery disconnect igniter for high voltage

Front driver side head airbag Front passenger side head airbag Front driver side pretensioner

Passenger airbag key contact switch

3rd row passenger side seat belt pretensioner 3rd row driver side seat belt pretensioner Front passenger side lateral airbag

Rear passenger side lateral airbag

Windowbag

Pre-crash system: rear seatbelt pretensioner - right side Pre-crash system: front seatbelt pretensioner - left side Pre-crash system: front seatbelt pretensioner - right side

CITROEN - C5 X [2021] (ND_, NC_)

Rear left side corner radar: dynamic calibration Real right side corner radar: dynamic calibration

CUPRA - BORN [2021] (K1)

Drive shaft load counter: reset
Production mode deactivation
Adaptation values reset
Saving of ECU coding on file
Writing of ECU coding from file
Delay management: rear camera

Text display on dashboard

Brake lights

Brake roller test operating mode: deactivation

Brake circuit bleeding

ECU coding

Electro-mechanical parking brake function test

Hydraulic brake assistant

Hydraulic pump

Basic setting for brake pressure sensor

Straight brake stabilization

Hydraulic test

Tire pressure monitoring system: factory setting reset

Overboost in brake system

Brake roller test operating mode: activation

Parking brake pads replacement: open brake clamps Parking brake pads replacement: close brake clamps

CUPRA - BORN [2021] (K1)

Brake pre-filling

Delay management: multiple collision brake Delay management: parking assistant

Basic setting of ESP sensors

Delay management: emergency assistant

Delay management: stopping distance reduction

Delay management: rear cross traffic assistant

Delay management: trailer maneuvering assistant

Delay management: pedestrian protection

ABS in lower speed range Hydraulic valves check

Parking brake actuator: opening
Parking brake actuator: closing
Brake roller test operating mode
Resetting of all adaptations
Delay management: ACC

High voltage battery: coolant valve 1 High voltage battery: coolant pump High voltage battery: coolant valve 2

High voltage battery: heater

Serial number of high-voltage / hybrid battery

ZSB part number Brake light switch Brakes test switch Brake pedal

All adaptation values reset

Leak test

Brake pedal position sensor basic setting

Brake booster bleeding Sluggishness test Radiator shutters Coolant pump Radiator fan 1

Cooling system bleeding

Drive type reset

Vehicle maintenance instructions

INSP: max days until next time dependent inspection

INSP: days elapsed since last time dependent inspection

Activation of views

Display contents lock

INSP: Max distance until next mileage dependent inspections INSP: Distance driven since last mileage dependent inspection

Inspection reset
Charging socket: flap
Charging socket: plug
Locking cycles counter reset

High-voltage system: lock release after crash

Hardware in loop mode

Battery charger A connector: number of successful charge plug

lockinas

Battery charger A connector cover: number of lockings Battery charger A connector: connections number Battery charger A connector: lockings number

Front left belt pretensioner Front right belt pretensioner

Crash severity management: front, driver side
Crash severity management: front, passenger side
Crash severity management: lateral, passenger side
Crash severity management: rear, passenger side
Crash severity management: pedestrian protection

Vehicle conditioning

Crash-active head restraint Passenger knees airbag Pedestrian crash sensor

Driver Airbag

Crash severity management: rear, driver side Crash severity management: lateral, driver side

Crash severity management: rollover
Rear driver side seat belt pretensioner
Rear passenger side seat belt pretensioner
Igniter for deactivation of A/C system 1

Warning messages

Passenger airbag deactivation warning lamp (if present)

Driver knees airbag

Belt pretensioner basic setting Assistance system monitoring

CUPRA - BORN [2021] (K1)

Front passenger interaction airbag

Passenger airbag

Front driver side lateral airbag
Front passenger side pretensioner
High voltage battery 3 disconnect igniter
Occupied seat recognition, driver side

3rd row center pretensioner

Igniter for deactivation of A/C system 2

Occupied seat recognition, front passenger side

Active head restraint activations reset
Passenger side active headrest
Rear driver side lateral airbag
Battery Disconnect Igniter

Rear passenger interaction airbag
High voltage battery 2 disconnect igniter
DC/DC converter disconnect igniter

Rollover protection system
Rear driver side head airbag
Rear passenger side head airbag
Pre-crash system: rear left belt feeder
Pre-crash system: rear right belt feeder

Driver side active headrest

Rear central seat belt pretensioner squib

2nd battery disconnect igniter

Pre-crash system: rear seatbelt pretensioner - left side

Battery disconnect igniter for high voltage

Front driver side head airbag
Front passenger side head airbag
Front driver side pretensioner
Passenger airbag key contact switch

3rd row passenger side seat belt pretensioner

3rd row driver side seat belt pretensioner Front passenger side lateral airbag Rear passenger side lateral airbag

Windowbag

Pre-crash system: rear seatbelt pretensioner - right side Pre-crash system: front seatbelt pretensioner - left side Pre-crash system: front seatbelt pretensioner - right side

CUPRA - FORMENTOR [2020] (KM)

Front left belt pretensioner Front right belt pretensioner

Crash severity management: front, driver side
Crash severity management: front, passenger side
Crash severity management: lateral, passenger side
Crash severity management: rear, passenger side
Crash severity management: pedestrian protection

Vehicle conditioning Crash-active head restraint Passenger knees airbag Pedestrian crash sensor

Driver Airbag

Crash severity management: rear, driver side Crash severity management: lateral, driver side

Crash severity management: rollover
Rear driver side seat belt pretensioner
Rear passenger side seat belt pretensioner
Igniter for deactivation of A/C system 1

Warning messages

Passenger airbag deactivation warning lamp (if present)

Driver knees airbag

Belt pretensioner basic setting Assistance system monitoring Front passenger interaction airbag

Passenger airbag

Front driver side lateral airbag
Front passenger side pretensioner
High voltage battery 3 disconnect igniter
Occupied seat recognition, driver side

3rd row center pretensioner

Igniter for deactivation of A/C system 2

Occupied seat recognition, front passenger side

Active head restraint activations reset
Passenger side active headrest
Rear driver side lateral airbag
Battery Disconnect Igniter

Rear passenger interaction airbag High voltage battery 2 disconnect igniter

CUPRA - FORMENTOR [2020] (KM)

DC/DC converter disconnect igniter

Rollover protection system

Rear driver side head airbag

Rear passenger side head airbag

Pre-crash system: rear left belt feeder

Pre-crash system: rear right belt feeder

Driver side active headrest

Rear central seat belt pretensioner squib

2nd battery disconnect igniter

Pre-crash system: rear seatbelt pretensioner - left side

Battery disconnect igniter for high voltage

Front driver side head airbag
Front passenger side head airbag
Saving of ECU coding on file
Writing of ECU coding from file
Front driver side pretensioner

Passenger airbag key contact switch

3rd row passenger side seat belt pretensioner 3rd row driver side seat belt pretensioner Front passenger side lateral airbag Rear passenger side lateral airbag

Windowbag

Pre-crash system: rear seatbelt pretensioner - right side Pre-crash system: front seatbelt pretensioner - left side Pre-crash system: front seatbelt pretensioner - right side

CUPRA - LEON [2020] (KL)

Front left belt pretensioner Front right belt pretensioner

Crash severity management: front, driver side
Crash severity management: front, passenger side
Crash severity management: lateral, passenger side
Crash severity management: rear, passenger side
Crash severity management: pedestrian protection

Vehicle conditioning
Crash-active head restraint
Passenger knees airbag

Pedestrian crash sensor

Driver Airbag

Crash severity management: rear, driver side Crash severity management: lateral, driver side

Crash severity management: rollover
Rear driver side seat belt pretensioner
Rear passenger side seat belt pretensioner
Igniter for deactivation of A/C system 1

Warning messages

Passenger airbag deactivation warning lamp (if present)

Driver knees airbag

Belt pretensioner basic setting
Assistance system monitoring
Front passenger interaction airbag

Passenger airbag

Front driver side lateral airbag
Front passenger side pretensioner
High voltage battery 3 disconnect igniter
Occupied seat recognition, driver side

3rd row center pretensioner

Igniter for deactivation of A/C system 2

Occupied seat recognition, front passenger side

Active head restraint activations reset
Passenger side active headrest
Rear driver side lateral airbag
Battery Disconnect Igniter

Rear passenger interaction airbag High voltage battery 2 disconnect igniter DC/DC converter disconnect igniter

Rollover protection system
Rear driver side head airbag
Rear passenger side head airbag
Pre-crash system: rear left belt feeder
Pre-crash system: rear right belt feeder

Driver side active headrest

Rear central seat belt pretensioner squib

2nd battery disconnect igniter

Pre-crash system: rear seatbelt pretensioner - left side

Battery disconnect igniter for high voltage

Front driver side head airbag
Front passenger side head airbag
Saving of ECU coding on file

CUPRA - LEON [2020] (KL)

Writing of ECU coding from file

Front driver side pretensioner

Passenger airbag key contact switch

3rd row passenger side seat belt pretensioner

3rd row driver side seat belt pretensioner

Front passenger side lateral airbag

Rear passenger side lateral airbag

Windowbag

Pre-crash system: rear seatbelt pretensioner - right side Pre-crash system: front seatbelt pretensioner - left side Pre-crash system: front seatbelt pretensioner - right side

LEXUS - LC [2016] (Z10)

Check mode: enable

LEXUS - LS [2017] (F5)

Check mode: enable

LEXUS - RX [2016-2022] (L2)

Check mode: enable

LEXUS - UX [2018] (ZA10)

Check mode: enable

MERCEDES BENZ - EQC [2019] (293)

Coolant pumps release

Coolant pumps lock

Coolant circulation pump

Coolant pump 1: high-temperature circuit Coolant pump 2: low-temperature circuit

High-voltage battery cooling switchover valve

Battery heater check

Electronic contacting check of coolant pumps via LIN bus

Electrical contacting check of 87M relay

Electrical contacting check of fans

Electric vacuum pump check

Resetting of vacuum pump runtime

Bleeding of passenger compartment / high voltage battery coolant

circuit

Electric drivetrain: bleeding the coolant circuit

Unlocking of high-voltage component locks of all high-voltage

battery modules

Control module reset

MERCEDES BENZ - GLC [2015-2022] (X253)

Coolant pumps release

Coolant pumps lock

Coolant circulation pump

Coolant pump 1: high-temperature circuit

Coolant pump 2: low-temperature circuit

High-voltage battery cooling switchover valve

Battery heater check

Electronic contacting check of coolant pumps via LIN bus

Electrical contacting check of 87M relay

Electrical contacting check of fans

Electric vacuum pump check

Resetting of vacuum pump runtime

Bleeding of passenger compartment / high voltage battery coolant

circuit

Electric drivetrain: bleeding the coolant circuit

Unlocking of high-voltage component locks of all high-voltage

battery modules

Control module reset

MERCEDES BENZ - SPRINTER [2018] (907-910)

Coolant pumps release

Coolant pumps lock

Coolant circulation pump

Coolant pump 1: high-temperature circuit

Coolant pump 2: low-temperature circuit

High-voltage battery cooling switchover valve

Battery heater check

Electronic contacting check of coolant pumps via LIN bus

Electrical contacting check of 87M relay

Electrical contacting check of fans

Electric vacuum pump check

Resetting of vacuum pump runtime

Bleeding of passenger compartment / high voltage battery coolant

circuit

MERCEDES BENZ - SPRINTER [2018] (907-910)

Electric drivetrain: bleeding the coolant circuit

Unlocking of high-voltage component locks of all high-voltage

battery modules

Control module reset

MERCEDES BENZ - V [2014] (447)

Coolant pumps release

Coolant pumps lock

Coolant circulation pump

Coolant pump 1: high-temperature circuit

Coolant pump 2: low-temperature circuit

High-voltage battery cooling switchover valve

Battery heater check

Electronic contacting check of coolant pumps via LIN bus

Electrical contacting check of 87M relay

Electrical contacting check of fans

Electric vacuum pump check

Resetting of vacuum pump runtime

Bleeding of passenger compartment / high voltage battery

coolant circuit

Electric drivetrain: bleeding the coolant circuit

Unlocking of high-voltage component locks of all high-voltage

battery modules

Control module reset

PEUGEOT - 308 [2021] (P5)

Rear left side corner radar: dynamic calibration

Real right side corner radar: dynamic calibration

PEUGEOT - 408 [2022]

Real right side corner radar: dynamic calibration

Rear left side corner radar: dynamic calibration

PORSCHE - MACAN [2013] (95B)

ECU coding

Saving of ECU coding on file

Writing of ECU coding from file

Tire pressure monitoring system (TPMS): wheels sensors ID

codes Writing

SEAT - LEON [2020] (KL)

Fuel pump

EGR valve 1

Radiator shutters

Reducing agent (AdBlue) heater

Reducing agent (AdBlue) heater 2

Coolant pump for intercooler

Radiator 1 fan command

Preheating glow 1 control unit

Exhaust flap

EGR valve 2

Compression test

Particulate filter forced regeneration (moving vehicle)

Particulate filter forced regeneration (stationary vehicle)

CAN communication monitoring reset

Test of disassembled turbocharger actuator

Fuel high pressure system: leakage measuring point

Switchable coolant pump

Control deviation test of exhaust gas recirculation system

Lambda probe test

Air mass flow meter plausibility test

Automatic glow time control unit test

Turbocharger Test

Fuel circuit bleeding

Reset reducing agent (AdBlue) lock

Manual test on exhaust flap

Charge pressure actuator test

Automatic test of low pressure EGR valve

Radiator shutters adaptation

Fuel high pressure system: engine start leak test

Reducing agent (AdBlue) duct emptying

Catalytic converter aging reset

Adaptation of correction angle of camshaft position detection:

angle sensor error (outlet side)

Adaptation of correction angle of camshaft position detection:

angle sensor error (inlet side)

Oil pump pressure level change-over test

Fuel tank emptying

Adaptation of correction angle of camshaft position detection:

phonic wheel angle sensor error (inlet side)

Fuel system flow rate test

SEAT - LEON [2020] (KL)

Reducing agent system quality sensor adaptation

Reducing agent quality test

Reducing agent (AdBlue) metering quantity test: injector 1

Reduction agent (AdBlue) system complete test

Reducing agent (AdBlue) metering quantity test: injector 2

Brake roller test operating mode

Start/Stop function

Exhaust Gas Recirculation valve (EGR) test Setting of soot mass value in anti particulate filter

Adaptation of correction angle of camshaft position detection:

phonic wheel angle sensor error (outlet side)

Front left belt pretensioner
Front right belt pretensioner

Crash severity management: front, driver side
Crash severity management: front, passenger side
Crash severity management: lateral, passenger side
Crash severity management: rear, passenger side
Crash severity management: pedestrian protection

Vehicle conditioning
Crash-active head restraint
Passenger knees airbag
Pedestrian crash sensor

Crash severity management: rear, driver side

Crash severity management: lateral, driver side

Crash severity management: rollover
Rear driver side seat belt pretensioner
Rear passenger side seat belt pretensioner
Igniter for deactivation of A/C system 1

Warning messages

Driver Airbag

Passenger airbag deactivation warning lamp (if present)

Driver knees airbag

Belt pretensioner basic setting Assistance system monitoring Front passenger interaction airbag

Passenger airbag

Front driver side lateral airbag
Front passenger side pretensioner
High voltage battery 3 disconnect igniter

Occupied seat recognition, driver side

3rd row center pretensioner

Igniter for deactivation of A/C system 2

Occupied seat recognition, front passenger side

Active head restraint activations reset
Passenger side active headrest
Rear driver side lateral airbag
Battery Disconnect Igniter

Rear passenger interaction airbag High voltage battery 2 disconnect igniter DC/DC converter disconnect igniter

Rollover protection system
Rear driver side head airbag
Rear passenger side head airbag
Pre-crash system: rear left belt feeder
Pre-crash system: rear right belt feeder

Driver side active headrest

Rear central seat belt pretensioner squib

2nd battery disconnect igniter

Pre-crash system: rear seatbelt pretensioner - left side

Battery disconnect igniter for high voltage

Front driver side head airbag
Front passenger side head airbag
Saving of ECU coding on file
Writing of ECU coding from file
Front driver side pretensioner

Passenger airbag key contact switch

3rd row passenger side seat belt pretensioner 3rd row driver side seat belt pretensioner Front passenger side lateral airbag Rear passenger side lateral airbag

Windowbag

Pre-crash system: rear seatbelt pretensioner - right side Pre-crash system: front seatbelt pretensioner - left side Pre-crash system: front seatbelt pretensioner - right side

SKODA - ENYAQ [2020] (NY)

Drive shaft load counter: reset
Production mode deactivation
Adaptation values reset

SKODA - ENYAQ [2020] (NY)

Saving of ECU coding on file
Writing of ECU coding from file
Delay management: rear camera
Text display on dashboard

Brake lights

Brake roller test operating mode: deactivation

Brake circuit bleeding

ECU coding

Electro-mechanical parking brake function test

Hydraulic brake assistant

Hydraulic pump

Basic setting for brake pressure sensor

Straight brake stabilization

Hydraulic test

Tire pressure monitoring system: factory setting reset

Overboost in brake system

Brake roller test operating mode: activation

Parking brake pads replacement: open brake clamps Parking brake pads replacement: close brake clamps

Brake pre-filling

Delay management: multiple collision brake Delay management: parking assistant

Basic setting of ESP sensors

Delay management: emergency assistant
Delay management: stopping distance reduction
Delay management: rear cross traffic assistant
Delay management: trailer maneuvering assistant

Delay management: pedestrian protection

ABS in lower speed range Hydraulic valves check

Parking brake actuator: opening Parking brake actuator: closing Brake roller test operating mode Resetting of all adaptations Delay management: ACC

High voltage battery: coolant valve 1 High voltage battery: coolant pump High voltage battery: coolant valve 2

High voltage battery: heater

Serial number of high-voltage / hybrid battery

ZSB part number Radiator shutters Coolant pump Radiator fan 1

Cooling system bleeding

Drive type reset

Vehicle maintenance instructions

INSP: max days until next time dependent inspection INSP: days elapsed since last time dependent inspection

Activation of views

Display contents lock

INSP: Max distance until next mileage dependent inspections INSP: Distance driven since last mileage dependent inspection

Inspection reset
Charging socket: flap
Charging socket: plug
Locking cycles counter reset

High-voltage system: lock release after crash

Hardware in loop mode

Battery charger A connector: number of successful charge plug

lockings

Battery charger A connector cover: number of lockings Battery charger A connector: connections number Battery charger A connector: lockings number

Front left belt pretensioner
Front right belt pretensioner

Crash severity management: front, driver side
Crash severity management: front, passenger side
Crash severity management: lateral, passenger side
Crash severity management: rear, passenger side
Crash severity management: pedestrian protection

Vehicle conditioning Crash-active head restraint Passenger knees airbag

Pedestrian crash sensor

Driver Airbag

Crash severity management: rear, driver side Crash severity management: lateral, driver side

Crash severity management: rollover

SKODA - ENYAQ [2020] (NY)

Rear driver side seat belt pretensioner Rear passenger side seat belt pretensioner Igniter for deactivation of A/C system 1

Warning messages

Passenger airbag deactivation warning lamp (if present)

Driver knees airbag

Belt pretensioner basic setting Assistance system monitoring Front passenger interaction airbag

Passenger airbag

Front driver side lateral airbag
Front passenger side pretensioner
High voltage battery 3 disconnect igniter
Occupied seat recognition, driver side

3rd row center pretensioner

Igniter for deactivation of A/C system 2

Occupied seat recognition, front passenger side

Active head restraint activations reset
Passenger side active headrest
Rear driver side lateral airbag
Battery Disconnect Igniter
Rear passenger interaction airbag

High voltage battery 2 disconnect igniter

DC/DC converter disconnect igniter

Rollover protection system
Rear driver side head airbag
Rear passenger side head airbag
Pre-crash system: rear left belt feeder
Pre-crash system: rear right belt feeder

Driver side active headrest

Rear central seat belt pretensioner squib

2nd battery disconnect igniter

Pre-crash system: rear seatbelt pretensioner - left side

Battery disconnect igniter for high voltage

Front driver side head airbag
Front passenger side head airbag
Front driver side pretensioner
Passenger airbag key contact switch

3rd row passenger side seat belt pretensioner

3rd row driver side seat belt pretensioner

Front passenger side lateral airbag Rear passenger side lateral airbag

Windowbag

Pre-crash system: rear seatbelt pretensioner - right side Pre-crash system: front seatbelt pretensioner - left side Pre-crash system: front seatbelt pretensioner - right side

SKODA - OCTAVIA [2020] (NX)

All adaptation values reset

ECU coding

Brake roller test operating mode
Oil pressure reservoir emptying
Installation information adaptation

Transmission hydraulic pump: basic setting

Clutch: adaptation values reset

Disengagement clutch: characteristic curve reset

Transmission: basic setting

Gear actuator and dual clutch: basic setting

Disengagement clutch: basic setting Gear actuator: adaptation values reset Start double clutch fast adaptation Saving of ECU coding on file

Clutch characteristic curve: adaptation values reset Disengagement clutch: adaptation values reset

Set gearbox mileage to vehicle mileage

Gearbox mileage reset
Set clutch mileage to zero
Writing of ECU coding from file
Oil pressure reservoir filling
Check transmission fluid level
Transmission fluid emptying
Transmission fluid filling

Syncronization points calibration

Fuel pump EGR valve 1 Radiator shutters

Reducing agent (AdBlue) heater Reducing agent (AdBlue) heater 2 Coolant pump for intercooler

SKODA - OCTAVIA [2020] (NX)

Radiator 1 fan command Preheating glow 1 control unit

Exhaust flap
EGR valve 2
Compression test

Particulate filter forced regeneration (moving vehicle)
Particulate filter forced regeneration (stationary vehicle)

CAN communication monitoring reset

Test of disassembled turbocharger actuator

Fuel high pressure system: leakage measuring point

Switchable coolant pump

Control deviation test of exhaust gas recirculation system

Lambda probe test

Air mass flow meter plausibility test Automatic glow time control unit test

Turbocharger Test Fuel circuit bleeding

Reset reducing agent (AdBlue) lock

Manual test on exhaust flap Charge pressure actuator test

Automatic test of low pressure EGR valve

Radiator shutters adaptation

Fuel high pressure system: engine start leak test

Reducing agent (AdBlue) duct emptying

Catalytic converter aging reset

Adaptation of correction angle of camshaft position detection:

angle sensor error (outlet side)

Adaptation of correction angle of camshaft position detection:

angle sensor error (inlet side)

Oil pump pressure level change-over test

Fuel tank emptying

Adaptation of correction angle of camshaft position detection:

phonic wheel angle sensor error (inlet side)

Fuel system flow rate test

Reducing agent system quality sensor adaptation

Reducing agent quality test

Reducing agent (AdBlue) metering quantity test: injector 1

Reduction agent (AdBlue) system complete test

Reducing agent (AdBlue) metering quantity test: injector 2

Start/Stop function

Exhaust Gas Recirculation valve (EGR) test Setting of soot mass value in anti particulate filter

Adaptation of correction angle of camshaft position detection:

phonic wheel angle sensor error (outlet side)

Fuel metering valve Fuel tank vent valve

Gas fuel tank shut-off valve Exhaust bypass valve

Camshaft adjustment inlet side bank 1

Coolant recirculation pump 2

Engine cooling fan 1

Radiator shutter 2: position (target value)

Turbocharger adaptation

Operating mode switching (ignition dependant)
Operating mode switching (mileage dependant)
Camshaft adjustment exhaust side bank 1
Engine temperature management actuator
Natural gas fuel system: pressure restore

Throttle valve adaptation test Fuel tank ventilation valve test

Natural gas (CNG): quality (target value) Radiator shutter 1: position (target value)

Camshaft synchronization test Engine run-in oil pressure

Test of mixture deviation in gas operation Intake manifold pressure calibration

Autonomous mode activation

Natural gas fuel system: pressure reduction

Injectors adaptation values reset
Lambda probe regulation test
Exhaust camshaft adjustment test

Lambda probe heater test downstream catalyst

Bank 1 lambda probe 1 heater test Phonic wheel: adaption values reset Injector valves: adaption values reset Phonic wheel: fine adaption values reset

Adaptation of camshaft correction angle: cylinder 1 (inlet side)

Charge pressure actuator adaptation

Coolant circuit bleeding

SKODA - OCTAVIA [2020] (NX)

Adaptation of camshaft correction angle: cylinder 4 (inlet side)
Adaptation of camshaft correction angle: cylinder 4 (outlet side)
Adaptation of camshaft correction angle: cylinder 3 (outlet side)
Adaptation of camshaft correction angle: cylinder 2 (outlet side)
Fuel supply system test

Oxygen sensors and catalytic converter check Crankshaft phonic wheel: adaption values reset

Adaptation of camshaft correction angle: cylinder 2 (inlet side) Adaptation of camshaft correction angle: cylinder 3 (inlet side) Adaptation of correction angle of camshaft position detection:

phonic wheel angle sensor error

Adaptation of camshaft correction angle: cylinder 1 (outlet side)

Rail pressure reduction

Throttle valve adaptive value resetting
Gear neutral position sensor adaptation
Intake camshaft adjustment check
Cylinder-specific pre-ignition counter reset

Adaptation of correction angle of camshaft position detection:

angle sensor error
Warming up phase 2
Warming up phase 1
Front left belt pretensioner
Front right belt pretensioner

Crash severity management: front, driver side
Crash severity management: front, passenger side
Crash severity management: lateral, passenger side
Crash severity management: rear, passenger side
Crash severity management: pedestrian protection

Vehicle conditioning
Crash-active head restraint
Passenger knees airbag
Pedestrian crash sensor

Driver Airbag

Crash severity management: rear, driver side Crash severity management: lateral, driver side

Crash severity management: rollover
Rear driver side seat belt pretensioner
Rear passenger side seat belt pretensioner
Igniter for deactivation of A/C system 1

Warning messages

Passenger airbag deactivation warning lamp (if present)

Driver knees airbag

Belt pretensioner basic setting Assistance system monitoring Front passenger interaction airbag

Passenger airbag

Front driver side lateral airbag
Front passenger side pretensioner
High voltage battery 3 disconnect igniter
Occupied seat recognition, driver side

3rd row center pretensioner

Igniter for deactivation of A/C system 2

Occupied seat recognition, front passenger side

Active head restraint activations reset
Passenger side active headrest
Rear driver side lateral airbag
Battery Disconnect Igniter
Rear passenger interaction airbag

High voltage battery 2 disconnect igniter DC/DC converter disconnect igniter

Rollover protection system

Rear driver side head airbag

Rear passenger side head airbag

Pre-crash system: rear left belt feeder

Pre-crash system: rear right belt feeder

Driver side active headrest

Rear central seat belt pretensioner squib

2nd battery disconnect igniter

Pre-crash system: rear seatbelt pretensioner - left side

Battery disconnect igniter for high voltage

Front driver side head airbag
Front passenger side head airbag
Front driver side pretensioner

Passenger airbag key contact switch

3rd row passenger side seat belt pretensioner 3rd row driver side seat belt pretensioner Front passenger side lateral airbag

Rear passenger side lateral airbag

Windowbag

SKODA - OCTAVIA [2020] (NX)

Pre-crash system: rear seatbelt pretensioner - right side Pre-crash system: front seatbelt pretensioner - left side Pre-crash system: front seatbelt pretensioner - right side

SKODA - SUPERB [2015] (3V)

Fuel pump

EGR valve 1

Radiator shutters

Reducing agent (AdBlue) heater Reducing agent (AdBlue) heater 2 Coolant pump for intercooler

Radiator 1 fan command

Preheating glow 1 control unit

Exhaust flap

EGR valve 2

Compression test

Particulate filter forced regeneration (moving vehicle)
Particulate filter forced regeneration (stationary vehicle)

CAN communication monitoring reset

Test of disassembled turbocharger actuator

Fuel high pressure system: leakage measuring point

Switchable coolant pump

Control deviation test of exhaust gas recirculation system

Lambda probe test

Air mass flow meter plausibility test Automatic glow time control unit test

Turbocharger Test Fuel circuit bleeding

Reset reducing agent (AdBlue) lock

Manual test on exhaust flap Charge pressure actuator test

Automatic test of low pressure EGR valve

Radiator shutters adaptation

Fuel high pressure system: engine start leak test

Reducing agent (AdBlue) duct emptying

Catalytic converter aging reset

Adaptation of correction angle of camshaft position detection:

angle sensor error (outlet side)

Adaptation of correction angle of camshaft position detection:

angle sensor error (inlet side)

Oil pump pressure level change-over test

Fuel tank emptying

Adaptation of correction angle of camshaft position detection:

phonic wheel angle sensor error (inlet side)

Fuel system flow rate test

Reducing agent system quality sensor adaptation

Reducing agent quality test

Reducing agent (AdBlue) metering quantity test: injector 1

Reduction agent (AdBlue) system complete test

Reducing agent (AdBlue) metering quantity test: injector 2

Brake roller test operating mode

Start/Stop function

Exhaust Gas Recirculation valve (EGR) test

Setting of soot mass value in anti particulate filter

Adaptation of correction angle of camshaft position detection:

phonic wheel angle sensor error (outlet side)

SUZUKI - ACROSS [2020] (A5Z)

Check mode: enable

SUZUKI - SWACE [2020] (AMZ)

Check mode: enable

TOYOTA - AVALON [2012-2018] (X4)

Check mode: enable

TOYOTA - C-HR [2016-2023] (X1)

Check mode: enable

TOYOTA - COROLLA [2019] (E21)

Check mode: enable

TOYOTA - NOAH [2014-2021] (R80)

Check mode: enable

TOYOTA - PRIUS [2016] (W5)

Check mode: enable

TOYOTA - RAV 4 V [2018] (A5)

Check mode: enable

TOYOTA - VOXY [2013-2021] (R80)

Check mode: enable

TOYOTA - YARIS [2020] (P21)

Check mode: enable

TOYOTA - YARIS CROSS [2020] (P21)

Check mode: enable

VOLKSWAGEN - ARTEON [2017]

Fuel pump EGR valve 1 Radiator shutters

Reducing agent (AdBlue) heater Reducing agent (AdBlue) heater 2 Coolant pump for intercooler Radiator 1 fan command Preheating glow 1 control unit

Exhaust flap EGR valve 2 Compression test

Particulate filter forced regeneration (moving vehicle)
Particulate filter forced regeneration (stationary vehicle)

CAN communication monitoring reset

Test of disassembled turbocharger actuator

Fuel high pressure system: leakage measuring point

Switchable coolant pump

Control deviation test of exhaust gas recirculation system

Lambda probe test

Air mass flow meter plausibility test Automatic glow time control unit test

Turbocharger Test Fuel circuit bleeding

Reset reducing agent (AdBlue) lock

Manual test on exhaust flap Charge pressure actuator test

Automatic test of low pressure EGR valve

Radiator shutters adaptation

Fuel high pressure system: engine start leak test

Reducing agent (AdBlue) duct emptying

Catalytic converter aging reset

Adaptation of correction angle of camshaft position detection:

angle sensor error (outlet side)

Adaptation of correction angle of camshaft position detection:

angle sensor error (inlet side)

Oil pump pressure level change-over test

Fuel tank emptying

Adaptation of correction angle of camshaft position detection:

phonic wheel angle sensor error (inlet side)

Fuel system flow rate test

Reducing agent system quality sensor adaptation

Reducing agent quality test

Reducing agent (AdBlue) metering quantity test: injector 1

Reduction agent (AdBlue) system complete test

Reducing agent (AdBlue) metering quantity test: injector 2

Brake roller test operating mode

Start/Stop function

Exhaust Gas Recirculation valve (EGR) test Setting of soot mass value in anti particulate filter

Adaptation of correction angle of camshaft position detection:

phonic wheel angle sensor error (outlet side)

VOLKSWAGEN - CADDY V [2020] (SB)

Natural gas (CNG): warning reset

Natural gas (CNG): time to next maintenance

Front left belt pretensioner
Front right belt pretensioner

Crash severity management: front, driver side
Crash severity management: front, passenger side
Crash severity management: lateral, passenger side
Crash severity management: rear, passenger side
Crash severity management: pedestrian protection

Vehicle conditioning

Crash-active head restraint
Passenger knees airbag
Pedestrian crash sensor

Driver Airbag

Crash severity management: rear, driver side Crash severity management: lateral, driver side

Crash severity management: rollover

VOLKSWAGEN - CADDY V [2020] (SB)

Rear driver side seat belt pretensioner

Rear passenger side seat belt pretensioner

Igniter for deactivation of A/C system 1

Warning messages

Passenger airbag deactivation warning lamp (if present)

Driver knees airbag

Belt pretensioner basic setting

Assistance system monitoring

Front passenger interaction airbag

Passenger airbag

Front driver side lateral airbag

Front passenger side pretensioner

High voltage battery 3 disconnect igniter

Occupied seat recognition, driver side

3rd row center pretensioner

Igniter for deactivation of A/C system 2

Occupied seat recognition, front passenger side

Active head restraint activations reset

Passenger side active headrest

Rear driver side lateral airbag

Battery Disconnect Igniter

Rear passenger interaction airbag

High voltage battery 2 disconnect igniter

DC/DC converter disconnect igniter

Rollover protection system

Rear driver side head airbag

Rear passenger side head airbag

Pre-crash system: rear left belt feeder

Pre-crash system: rear right belt feeder

Driver side active headrest

Rear central seat belt pretensioner squib

2nd battery disconnect igniter

Pre-crash system: rear seatbelt pretensioner - left side

Battery disconnect igniter for high voltage

Front driver side head airbag

Front passenger side head airbag

Saving of ECU coding on file

Writing of ECU coding from file

Front driver side pretensioner

Passenger airbag key contact switch

3rd row passenger side seat belt pretensioner

3rd row driver side seat belt pretensioner

Front passenger side lateral airbag

Rear passenger side lateral airbag

Windowbag

Pre-crash system: rear seatbelt pretensioner - right side Pre-crash system: front seatbelt pretensioner - left side Pre-crash system: front seatbelt pretensioner - right side

VOLKSWAGEN - FOX [2005-2014] (5Z)

Activations

Steering wheel angle sensor calibration

ECU coding

Basic setting-advance mode

Adaptation (Advanced mode)

Login

Security access

ABS purge

System function test

VOLKSWAGEN - GOLF VIII [2020] (CD)

Fuel pump

EGR valve 1

Radiator shutters

Reducing agent (AdBlue) heater

Reducing agent (AdBlue) heater 2

Coolant pump for intercooler

Radiator 1 fan command

Preheating glow 1 control unit

Exhaust flap

EGR valve 2

Compression test

Particulate filter forced regeneration (moving vehicle)

Particulate filter forced regeneration (stationary vehicle)

CAN communication monitoring reset

Test of disassembled turbocharger actuator

Fuel high pressure system: leakage measuring point

Switchable coolant pump

Control deviation test of exhaust gas recirculation system

VOLKSWAGEN - GOLF VIII [2020] (CD)

Lambda probe test

Air mass flow meter plausibility test Automatic glow time control unit test

Turbocharger Test Fuel circuit bleeding

Reset reducing agent (AdBlue) lock

Manual test on exhaust flap Charge pressure actuator test

Automatic test of low pressure EGR valve

Radiator shutters adaptation

Fuel high pressure system: engine start leak test

Reducing agent (AdBlue) duct emptying

Catalytic converter aging reset

Adaptation of correction angle of camshaft position detection:

angle sensor error (outlet side)

Adaptation of correction angle of camshaft position detection:

angle sensor error (inlet side)

Oil pump pressure level change-over test

Fuel tank emptying

Adaptation of correction angle of camshaft position detection:

phonic wheel angle sensor error (inlet side)

Fuel system flow rate test

Reducing agent system quality sensor adaptation

Reducing agent quality test

Reducing agent (AdBlue) metering quantity test: injector 1

Reduction agent (AdBlue) system complete test

Reducing agent (AdBlue) metering quantity test: injector 2 $\,$

Brake roller test operating mode

Start/Stop function

Exhaust Gas Recirculation valve (EGR) test Setting of soot mass value in anti particulate filter

Adaptation of correction angle of camshaft position detection:

phonic wheel angle sensor error (outlet side)

VOLKSWAGEN - ID.3 [2020] (E1)

Drive shaft load counter: reset Production mode deactivation

Adaptation values reset Saving of ECU coding on file Writing of ECU coding from file

Delay management: rear camera

Text display on dashboard

Brake lights

Brake roller test operating mode: deactivation

Brake circuit bleeding

ECU coding

Electro-mechanical parking brake function test

Hydraulic brake assistant

Hydraulic pump

Basic setting for brake pressure sensor

Straight brake stabilization

Hydraulic test

Tire pressure monitoring system: factory setting reset

Overboost in brake system

Brake roller test operating mode: activation

Parking brake pads replacement: open brake clamps Parking brake pads replacement: close brake clamps

Brake pre-filling

Delay management: multiple collision brake Delay management: parking assistant

Basic setting of ESP sensors

Delay management: emergency assistant

Delay management: stopping distance reduction
Delay management: rear cross traffic assistant
Delay management: trailer maneuvering assistant

Delay management: pedestrian protection

ABS in lower speed range Hydraulic valves check

Parking brake actuator: opening Parking brake actuator: closing Brake roller test operating mode Resetting of all adaptations

Delay management: ACC

High voltage battery: coolant valve 1 High voltage battery: coolant pump High voltage battery: coolant valve 2

High voltage battery: heater

Serial number of high-voltage / hybrid battery

ZSB part number

VOLKSWAGEN - ID.3 [2020] (E1)

Brake light switch
Brakes test switch
Brake pedal

All adaptation values reset

Leak test

Brake pedal position sensor basic setting

Brake booster bleeding Sluggishness test Radiator shutters Coolant pump Radiator fan 1

Cooling system bleeding

Drive type reset

Vehicle maintenance instructions

INSP: max days until next time dependent inspection INSP: days elapsed since last time dependent inspection

Activation of views

Display contents lock

INSP: Max distance until next mileage dependent inspections INSP: Distance driven since last mileage dependent inspection

Inspection reset
Charging socket: flap
Charging socket: plug
Locking cycles counter reset

High-voltage system: lock release after crash

Hardware in loop mode

Battery charger A connector: number of successful charge plug

lockinas

Battery charger A connector cover: number of lockings Battery charger A connector: connections number Battery charger A connector: lockings number

Front left belt pretensioner Front right belt pretensioner

Crash severity management: front, driver side
Crash severity management: front, passenger side
Crash severity management: lateral, passenger side
Crash severity management: rear, passenger side
Crash severity management: pedestrian protection

Vehicle conditioning

Crash-active head restraint Passenger knees airbag

Pedestrian crash sensor

Driver Airbag

Crash severity management: rear, driver side Crash severity management: lateral, driver side

Crash severity management: rollover
Rear driver side seat belt pretensioner
Rear passenger side seat belt pretensioner
Igniter for deactivation of A/C system 1

Warning messages

Passenger airbag deactivation warning lamp (if present)

Driver knees airbag

Belt pretensioner basic setting
Assistance system monitoring
Front passenger interaction airbag

Passenger airbag

Front driver side lateral airbag
Front passenger side pretensioner
High voltage battery 3 disconnect igniter
Occupied seat recognition, driver side

3rd row center pretensioner

Igniter for deactivation of A/C system 2

Occupied seat recognition, front passenger side

Active head restraint activations reset
Passenger side active headrest
Rear driver side lateral airbag
Battery Disconnect Igniter

Rear passenger interaction airbag High voltage battery 2 disconnect igniter DC/DC converter disconnect igniter

Rollover protection system
Rear driver side head airbag
Rear passenger side head airbag
Pre-crash system: rear left belt feeder
Pre-crash system: rear right belt feeder

Driver side active headrest

Rear central seat belt pretensioner squib

2nd battery disconnect igniter

Pre-crash system: rear seatbelt pretensioner - left side

VOLKSWAGEN - ID.3 [2020] (E1)

Battery disconnect igniter for high voltage

Front driver side head airbag
Front passenger side head airbag
Front driver side pretensioner

Passenger airbag key contact switch

3rd row passenger side seat belt pretensioner 3rd row driver side seat belt pretensioner Front passenger side lateral airbag Rear passenger side lateral airbag

Windowbag

Pre-crash system: rear seatbelt pretensioner - right side Pre-crash system: front seatbelt pretensioner - left side Pre-crash system: front seatbelt pretensioner - right side

VOLKSWAGEN - ID.4 [2020] (E21)

Drive shaft load counter: reset Production mode deactivation Adaptation values reset

Saving of ECU coding on file
Writing of ECU coding from file
Delay management: rear camera
Text display on dashboard

Brake lights

Brake roller test operating mode: deactivation

Brake circuit bleeding

ECU coding

Electro-mechanical parking brake function test

Hydraulic brake assistant

Hydraulic pump

Basic setting for brake pressure sensor

Straight brake stabilization

Hydraulic test

Tire pressure monitoring system: factory setting reset

Overboost in brake system

Brake roller test operating mode: activation

Parking brake pads replacement: open brake clamps Parking brake pads replacement: close brake clamps

Brake pre-filling

Delay management: multiple collision brake

Delay management: parking assistant

Basic setting of ESP sensors

Delay management: emergency assistant

Delay management: stopping distance reduction Delay management: rear cross traffic assistant Delay management: trailer maneuvering assistant

Delay management: pedestrian protection

ABS in lower speed range Hydraulic valves check

Parking brake actuator: opening
Parking brake actuator: closing
Brake roller test operating mode
Resetting of all adaptations
Delay management: ACC

High voltage battery: coolant valve 1 High voltage battery: coolant pump High voltage battery: coolant valve 2

High voltage battery: heater

Serial number of high-voltage / hybrid battery

ZSB part number Brake light switch Brakes test switch Brake pedal

All adaptation values reset

Leak test

Brake pedal position sensor basic setting

Brake booster bleeding Sluggishness test Radiator shutters Coolant pump Radiator fan 1

Cooling system bleeding

Drive type reset

Vehicle maintenance instructions

INSP: max days until next time dependent inspection INSP: days elapsed since last time dependent inspection

Activation of views

Display contents lock

INSP: Max distance until next mileage dependent inspections INSP: Distance driven since last mileage dependent inspection

VOLKSWAGEN - ID.4 [2020] (E21)

Inspection reset
Charging socket: flap
Charging socket: plug

Locking cycles counter reset

High-voltage system: lock release after crash

Hardware in loop mode

Battery charger A connector: number of successful charge plug

lockings

Battery charger A connector cover: number of lockings Battery charger A connector: connections number Battery charger A connector: lockings number

Front left belt pretensioner
Front right belt pretensioner

Crash severity management: front, driver side
Crash severity management: front, passenger side
Crash severity management: lateral, passenger side
Crash severity management: rear, passenger side
Crash severity management: pedestrian protection

Vehicle conditioning
Crash-active head restraint
Passenger knees airbag
Pedestrian crash sensor

Driver Airbag

Crash severity management: rear, driver side Crash severity management: lateral, driver side

Crash severity management: rollover
Rear driver side seat belt pretensioner
Rear passenger side seat belt pretensioner
Igniter for deactivation of A/C system 1

Warning messages

Passenger airbag deactivation warning lamp (if present)

Driver knees airbag

Belt pretensioner basic setting
Assistance system monitoring
Front passenger interaction airbag

Passenger airbag

Front driver side lateral airbag
Front passenger side pretensioner
High voltage battery 3 disconnect igniter

Occupied seat recognition, driver side

3rd row center pretensioner

Igniter for deactivation of A/C system 2

Occupied seat recognition, front passenger side

Active head restraint activations reset
Passenger side active headrest
Rear driver side lateral airbag
Battery Disconnect Igniter

Rear passenger interaction airbag High voltage battery 2 disconnect igniter DC/DC converter disconnect igniter

Rollover protection system
Rear driver side head airbag
Rear passenger side head airbag
Pre-crash system: rear left belt feeder
Pre-crash system: rear right belt feeder

Driver side active headrest

Rear central seat belt pretensioner squib

2nd battery disconnect igniter

Pre-crash system: rear seatbelt pretensioner - left side

Battery disconnect igniter for high voltage

Front driver side head airbag
Front passenger side head airbag
Front driver side pretensioner

Passenger airbag key contact switch

3rd row passenger side seat belt pretensioner 3rd row driver side seat belt pretensioner Front passenger side lateral airbag Rear passenger side lateral airbag

Windowbag

Pre-crash system: rear seatbelt pretensioner - right side Pre-crash system: front seatbelt pretensioner - left side Pre-crash system: front seatbelt pretensioner - right side

VOLKSWAGEN - ID.BUZZ [2022] (EB)

Drive shaft load counter: reset
Production mode deactivation
Adaptation values reset
Saving of ECU coding on file
Writing of ECU coding from file

VOLKSWAGEN - ID.BUZZ [2022] (EB)

Delay management: rear camera Text display on dashboard

Brake lights

Brake roller test operating mode: deactivation

Brake circuit bleeding

ECU coding

Electro-mechanical parking brake function test

Hydraulic brake assistant

Hydraulic pump

Basic setting for brake pressure sensor

Straight brake stabilization

Hydraulic test

Tire pressure monitoring system: factory setting reset

Overboost in brake system

Brake roller test operating mode: activation

Parking brake pads replacement: open brake clamps Parking brake pads replacement: close brake clamps

Brake pre-filling

Delay management: multiple collision brake Delay management: parking assistant

Basic setting of ESP sensors

Delay management: emergency assistant
Delay management: stopping distance reduction
Delay management: rear cross traffic assistant
Delay management: trailer maneuvering assistant
Delay management: pedestrian protection

ABS in lower speed range Hydraulic valves check

Parking brake actuator: opening
Parking brake actuator: closing
Brake roller test operating mode
Resetting of all adaptations
Delay management: ACC

High voltage battery: coolant valve 1 High voltage battery: coolant pump High voltage battery: coolant valve 2

High voltage battery: heater

Serial number of high-voltage / hybrid battery

ZSB part number Radiator shutters Coolant pump

Radiator fan 1

Cooling system bleeding

Drive type reset

Vehicle maintenance instructions

INSP: max days until next time dependent inspection INSP: days elapsed since last time dependent inspection

Activation of views

Display contents lock

INSP: Max distance until next mileage dependent inspections INSP: Distance driven since last mileage dependent inspection

Inspection reset
Charging socket: flap
Charging socket: plug
Locking cycles counter reset

High-voltage system: lock release after crash

Hardware in loop mode

Battery charger A connector: number of successful charge plug

lockings

Battery charger A connector cover: number of lockings Battery charger A connector: connections number Battery charger A connector: lockings number

VOLKSWAGEN - PASSAT [2014] (3G)

Fuel pump EGR valve 1 Radiator shutters

Reducing agent (AdBlue) heater Reducing agent (AdBlue) heater 2 Coolant pump for intercooler Radiator 1 fan command Preheating glow 1 control unit

Exhaust flap EGR valve 2 Compression test

Particulate filter forced regeneration (moving vehicle)
Particulate filter forced regeneration (stationary vehicle)

CAN communication monitoring reset

Test of disassembled turbocharger actuator

Fuel high pressure system: leakage measuring point

Switchable coolant pump

VOLKSWAGEN - PASSAT [2014] (3G)

Control deviation test of exhaust gas recirculation system

Lambda probe test

Air mass flow meter plausibility test

Automatic glow time control unit test

Turbocharger Test

Fuel circuit bleeding

Reset reducing agent (AdBlue) lock

Manual test on exhaust flap

Charge pressure actuator test

Automatic test of low pressure EGR valve

Radiator shutters adaptation

Fuel high pressure system: engine start leak test

Reducing agent (AdBlue) duct emptying

Catalytic converter aging reset

Adaptation of correction angle of camshaft position detection:

angle sensor error (outlet side)

Adaptation of correction angle of camshaft position detection:

angle sensor error (inlet side)

Oil pump pressure level change-over test

Fuel tank emptying

Adaptation of correction angle of camshaft position detection:

phonic wheel angle sensor error (inlet side)

Fuel system flow rate test

Reducing agent system quality sensor adaptation

Reducing agent quality test

Reducing agent (AdBlue) metering quantity test: injector 1

Reduction agent (AdBlue) system complete test

Reducing agent (AdBlue) metering quantity test: injector 2

Brake roller test operating mode

Start/Stop function

Exhaust Gas Recirculation valve (EGR) test

Setting of soot mass value in anti particulate filter

Adaptation of correction angle of camshaft position detection:

phonic wheel angle sensor error (outlet side)

VOLVO - S90 [2016] (234)

Fuel pump

MIL Lamp

Radiator grill shutter position command

Engine oil service reset

Diesel particulate filter pressure sensor adaptive values reset

Glow plug adaptation values reset

Self-adaptation parameters reset: injector 3

PowerPulse system: leakage test

Particulate filter adaptation values reset

Swirl valve actuator adaptation values reset

Crash event counter reset

Self-adaptation parameters reset: injector 1 Self-adaptation parameters reset: injector 2

DPF forced regeneration, stationary vehicle Self-adaptation parameters reset: injector 4

Fuel flow regulation valve adaptation value reset

NOx filter adaptation value reset PowerPulse system: one pulse PowerPulse system: emptying

Reset of variable geometry turbocharger actuator learned values

High pressure EGR valve adaptation values reset Front lambda probe adaptation values reset Rear lambda probe adaptation values reset

Erasing errors in all control units

DPF forced regeneration, moving vehicle

VOLVO - V90 [2016] (235, 236)

Fuel pump

MIL Lamp

Radiator grill shutter position command

Engine oil service reset

Diesel particulate filter pressure sensor adaptive values reset

Glow plug adaptation values reset

Self-adaptation parameters reset: injector 3

PowerPulse system: leakage test

Particulate filter adaptation values reset

Swirl valve actuator adaptation values reset

Crash event counter reset

Self-adaptation parameters reset: injector 1 Self-adaptation parameters reset: injector 2 DPF forced regeneration, stationary vehicle

Self-adaptation parameters reset: injector 4

Fuel flow regulation valve adaptation value reset

VOLVO - V90 [2016] (235, 236)

NOx filter adaptation value reset PowerPulse system: one pulse PowerPulse system: emptying

Reset of variable geometry turbocharger actuator learned values

High pressure EGR valve adaptation values reset Front lambda probe adaptation values reset Rear lambda probe adaptation values reset

Erasing errors in all control units

DPF forced regeneration, moving vehicle

VOLVO - XC90 [2014] (256)

Fuel pump

MIL Lamp

Radiator grill shutter position command

Engine oil service reset

Diesel particulate filter pressure sensor adaptive values reset

Glow plug adaptation values reset

Self-adaptation parameters reset: injector 3

PowerPulse system: leakage test
Particulate filter adaptation values reset
Swirl valve actuator adaptation values reset

Crash event counter reset

Self-adaptation parameters reset: injector 1
Self-adaptation parameters reset: injector 2
DPF forced regeneration, stationary vehicle
Self-adaptation parameters reset: injector 4
Fuel flow regulation valve adaptation value reset

NOx filter adaptation value reset PowerPulse system: one pulse PowerPulse system: emptying

Reset of variable geometry turbocharger actuator learned values

High pressure EGR valve adaptation values reset Front lambda probe adaptation values reset Rear lambda probe adaptation values reset

Erasing errors in all control units

DPF forced regeneration, moving vehicle

Model	System	Faults reading and erasure	Parameters and status reading	Activations	Adjustments	DoiP
AUDI		,				
> A3 [2012-2019] (8V)	STEERING LOCK	+				
> A3 [2020] (8Y)	AUTOMATIC GEARBOX	+	+		+	
> A3 [2020] (8Y)	EFI (ELECTRONIC PETROL INJECTION)	+	+	+	+	
	STEERING LOCK	+				
> A8 [2017] (4N)	STEERING LOCK	+				
> E-TRON [2018]	STEERING LOCK	+				
> Q2 [2016] (GA)	EFI (ELECTRONIC PETROL INJECTION)	+	+	+	+	
	STEERING LOCK	+				
> Q3 [2018] (3B)	AUTOMATIC GEARBOX	+	+	+		
	STEERING LOCK	+				
> Q4 e-tron [2021] (F4)	ELECTRIC VEHICLE WARNING SOUNDS	+	+	+	+	
	MOTOR GENERATOR	+	+	+	+	
> Q7 [2015-2020] (4M)	EDI (ELECTRONIC DIESEL INJECTION)	+	+	+	+	
> Q8 [2018] (4M)	EDI (ELECTRONIC DIESEL INJECTION)		+	+	+	
> Q8 E-TRON [2022] (GE)	ABS		+	+	+	
1 1 ,	AUTOMATIC GEARBOX	+	+	+	+	
	BATTERY PACK	- 	+	+	+	
	CAMERA CONTROL MODULE		+	+	+	
	CENTRAL GATEWAY		+	+	+	
	CHARGER SYSTEM		<u> </u>	- <u>- </u>		
	CHASSIS CONTROL MODULE	_ <u> </u>	+	+	+	
	COMFORT SYSTEM	_ <u> </u>	- · · · · · · · · · · · · · · · · · · ·	+	·	
	DASHBOARD		+	+	+	
	DCDC CONVERTER		+	+	+	
	DOORS SYSTEM		- 	+		
	ELECTRIC MOTOR		- 	·	+	
	ELECTRIC VEHICLE WARNING SOUNDS					
	ELECTRONIC CENTRAL ELECTRICS SYSTEM	+	+	+	+	
	EMERGENCY CALL MODULE (E-CALL)	+				
	FRONT CORNER RADAR	+	+		+	
	LANE CHANGE ASSIST (BLIND SPOT)		+	+	+	
	LIGHTS SYSTEM		+	+	+	
	MOTOR GENERATOR	_ <u>·</u>	- <u>·</u>	+	·	
	MULTIMEDIA SYSTEMS	_ <u>·</u>	- · · · · · · · · · · · · · · · · · · ·	·		
	PARKING ASSISTANCE SYSTEM	_ <u>·</u>	+		+	
	POWERSTEERING	_ <u>·</u>	- <u>·</u>		·	
	SRS (AIRBAG)	_ ·	- · · · · · · · · · · · · · · · · · · ·	+	+	
	STEERING CONTROL UNIT		- 	+	+	
	STEERING LOCK			· ——•	<u> </u>	
	THERMAL MANAGEMENT			+	+	
	I I ILNIVIAL IVIANAGLIVIEN I	<u> </u>	+		т	

Model	System	Faults reading and erasure	Parameters and status reading	Activations	Adjustments	DoiP
BMW						
> 1 [2011-2019] (F20)	EFI (ELECTRONIC PETROL INJECTION)	+	+	+	+	
> 2 [2014-2019] (F22-F23)	EDI (ELECTRONIC DIESEL INJECTION)	+	+	+	+	
	EFI (ELECTRONIC PETROL INJECTION)	+	+	+	+	
> 3 [2011-2019] (F30)	EFI (ELECTRONIC PETROL INJECTION)	+	+	+	+	
> 3 [2018] (G20)	EFI (ELECTRONIC PETROL INJECTION)	+	+	+	+	
> 4 [2013] (F32)	EFI (ELECTRONIC PETROL INJECTION)	+	+	+	+	
> 5 [2017] (G30)	EFI (ELECTRONIC PETROL INJECTION)	+	+	+	+	
> 6 [2017] (G32)	EFI (ELECTRONIC PETROL INJECTION)	+	+	+	+	
> 7 [2015-2022] (G11)	EFI (ELECTRONIC PETROL INJECTION)	+	+	+	+	
> X3 [2017] (G01)	EFI (ELECTRONIC PETROL INJECTION)	+	+	+	+	
CITROEN						
> C5 X [2021] (ND_, NC_)	RADAR	+	+		+	
CUPRA						
> BORN [2021] (K1)	STEERING LOCK	+				
> LEON [2020] (KL)	AUTOMATIC GEARBOX	+	+		+	
	STEERING LOCK	+	_			
DS						
> DS4 [2021] (F_, FB_, F3_)	AUTOMATIC GEARBOX	+	+	+	+	
	BODY COMPUTER	+	+	+	+	
	BRAKE ASSIST	+	+			
	DOORS SYSTEM	+		+	+	
	HYBRID CONTROL SYSTEM	+	+	+		
	LANE CHANGE ASSIST (BLIND SPOT)	+	+		+	
	MULTIFUNCTIONAL STEERING WHEEL	+				
	MULTIMEDIA SYSTEMS	+				
	PARKING ASSISTANCE SYSTEM	+	+	+	+	
	RADAR	+	+		+	
	RAIN/LIGHT SENSOR	+	+		+	
	SRS (AIRBAG)	+	+			
	STEERING CONTROL UNIT	+		+	+	
FIAT						
> 500 [2007] (312)	EDI (ELECTRONIC DIESEL INJECTION)	+	+	+	+	
> TIPO [2015] (356)	EFI (ELECTRONIC PETROL INJECTION)	+	+	+	+	

Model	System	Faults reading and erasure	Parameters and status reading	Activations	Adjustments	DoiP
FORD						
> TOURNEO CONNECT [2022]	ABS	+	+	+	+	
	CENTRAL GATEWAY	+	+	+	+	
	DASHBOARD	+	+	+	+	
	DOORS SYSTEM	+	+	+	+	
	EDI (ELECTRONIC DIESEL INJECTION)	+	+	+	+	
	ELECTRONIC CENTRAL ELECTRICS SYSTEM	+	+	+	+	
	PARKING ASSISTANCE SYSTEM	+	+	+	+	
	POWERSTEERING	+	+		+	
	SRS (AIRBAG)	+	+			
	STEERING LOCK	+				
HYUNDAI						
> IONIQ 5 [2021] (NE)	BATTERY PACK	+	+			>
	DCDC CONVERTER	+	+	-		
> KONA [2018] (OS)	BATTERY PACK	+	+			
JAGUAR		,				
> F-PACE [2015] (X761)	CRUISE CONTROL	+			+	
> I-PACE [2018] (X590)	ABS	_ +	+	+	+	+
	BATTERY PACK	+	+	+	+	+
	BODY COMPUTER	+	+	+	+	+
	BRAKE ASSIST	+	+	+	+	+
	CAMERA CONTROL MODULE	+	+		+	+
	CHARGER SYSTEM	+	+	+	+	+
	DASHBOARD	+	+		+	+
	DCDC CONVERTER	+	+	+	+	+
	ELECTRIC MOTOR	+	+	+	+	+
	SRS (AIRBAG)	+	+		+	
JEEP						
> AVENGER [2022] (J2)	ANTI-THEFT SYSTEM	+				
	AUXILIARY HEATING	+				
	BATTERY CONTROL SYSTEM	+	+	+	+	
	BATTERY PACK	+	+		+	
	CHARGER SYSTEM	+				
	DCDC CONVERTER	+	+			
	ELECTRIC MOTOR	+	+		+	
	GEAR SELECTION MODULE	+	+	+		
	MULTIFUNCTION DISPLAY	+				

Model	System	Faults reading and erasure	Parameters and status reading	Activations	Adjustments	DoiP
JEEP						
> AVENGER [2022] (J2)	MULTIMEDIA SYSTEMS	+				
	PARKING ASSISTANCE SYSTEM	+				
	RADAR	+	+	+	+	
	REAR ELECTRICAL MODULE	+				
	ROOF CONTROL UNIT	+				
	SEAT SYSTEM	+				
	STEERING LOCK	+				
	TOW BAR	+				
> RENEGADE [2014] (BU)	EDI (ELECTRONIC DIESEL INJECTION)	+	+	+	+	
	EFI (ELECTRONIC PETROL INJECTION)	+	+	+	+	
KIA						
> EV6 [2021] (CV)	BATTERY PACK	+	+			
> SPORTAGE [2021] (NQ)	EFI (ELECTRONIC PETROL INJECTION)	+	+			
> STONIC [2017] (YB)	RADAR	+	+		+	
MAZDA						
> CX-5 [2017] (KF)	EFI (ELECTRONIC PETROL INJECTION)	+	+	+	+	
MERCEDES BENZ		'		'		
> A [2012-2018] (176)	STEERING CONTROL UNIT	+	+	-	-	
> AMG GT [2014] (C190)	STEERING CONTROL UNIT	+	+			
> B [2011-2018] (246)	STEERING CONTROL UNIT	+	+			
> C [2007-2014] (204)	STEERING CONTROL UNIT	+	+			
> CLA [2013-2019] (117)	STEERING CONTROL UNIT	+	+			
> GLS [2015-2019] (X166)	STEERING CONTROL UNIT	+	+			
> E [2009-2016] (212)	STEERING CONTROL UNIT	+	+			
> E [2015] (213-238)	EDI (ELECTRONIC DIESEL INJECTION)	+	+	+	+	
	EFI (ELECTRONIC PETROL INJECTION)	+	+	+	+	
> EQA [2021] (243)	BATTERY PACK	+	+	+	+	
	CEILING LAMP	+				
	CHARGER SYSTEM	+	+	+	+	
	DCDC CONVERTER	+	+	+	+	
	DOORS SYSTEM	+				
	MULTIFUNCTION DISPLAY	+				
	MULTIMEDIA SYSTEMS	+				
	PLUG-IN CONNECTOR	+	+	+	+	
	POWERTRAIN CONTROL UNIT	+	+	+	+	

Model	System	Faults reading and erasure	Parameters and status reading	Activations	Adjustments	DoiP
MERCEDES BENZ						
> EQB [2021] (243)	BATTERY PACK	+	+	+	+	
	CEILING LAMP	+				
	CHARGER SYSTEM	+	+	+	+	
	DCDC CONVERTER	+	+	+	+	
	DOORS SYSTEM	+				
	MULTIFUNCTION DISPLAY	+				
	MULTIMEDIA SYSTEMS	+				
	PLUG-IN CONNECTOR	+	+	+	+	
	POWERTRAIN CONTROL UNIT	+	+	+	+	
> EQV [2021] (447)	BODY COMPUTER	+	+	+	+	
	DOORS SYSTEM	+	+	+	+	
	LIGHTS SYSTEM	+	+		·	
	RAIN/LIGHT SENSOR		+		·	
	STEERING CONTROL UNIT	+	+	· 	·	
> G [2018] (463)	STEERING CONTROL UNIT	+	+		·-	
> GL [2012-2015] (X166)	STEERING CONTROL UNIT	+	+			
> GLA [2013-2019] (X156)	STEERING CONTROL UNIT	+	+			
> GLE [2015-2018] (166)	STEERING CONTROL UNIT	+	+			
> GLE [2015-2019] (292)	STEERING CONTROL UNIT	+	+			
> GLS [2015-2019] (X166)	STEERING CONTROL UNIT	+	+			
> ML [2012-2015] (166)	STEERING CONTROL UNIT	+	+			
> SL [2011-2022] (231)	STEERING CONTROL UNIT	+	+			
> SLC [2016-2017] (172)	EDI (ELECTRONIC DIESEL INJECTION)	+	+	+	+	
2 ,	EFI (ELECTRONIC PETROL INJECTION)	+	+	+	+	
> SLK [2011] (172)	STEERING CONTROL UNIT	+	+			
> V [2014] (447)	BODY COMPUTER	+	+	+	+	
. [=]()	DOORS SYSTEM	+	+	+	+	
	LIGHTS SYSTEM	+	+			
	RAIN/LIGHT SENSOR		+			
	STEERING CONTROL UNIT	+	+			
> X [2017] (470)	STEERING CONTROL UNIT	+	+			
MINI						
> COUNTRYMAN [2016] (F60)	EDI (ELECTRONIC DIESEL INJECTION)	+	+	+	+	
MINI [2006-2013] (R56)	EDI (ELECTRONIC DIESEL INJECTION)	+	+	+	+	
MITSUBISHI	,					
> MIRAGE [2012]	EFI (ELECTRONIC PETROL INJECTION)	+	+	+	+	
> SPACE STAR [2013]	EFI (ELECTRONIC PETROL INJECTION)	+	+	+	+	

Model	System	Faults reading and erasure	Parameters and status reading	Activations	Adjustments	DoiP
NISSAN						
> JUKE [2010-2019] (F15)	PARKING ASSISTANCE SYSTEM	+	+	+	+	
> JUKE [2020] (F16)	ABS	+	+	+	+	
	AIR CONDITIONING	+	+	+	+	
	BODY COMPUTER	+	+	+	+	
	CENTRAL CONSOLE	+	-			
	EFI (ELECTRONIC PETROL INJECTION)	+	+	+	+	
	KEYLESS SYSTEM	+				
	MULTIMEDIA SYSTEMS	+	-			
	POWERSTEERING	+	+			
	SECURE GATEWAY	+	+			
> MICRA [2017] (K14)	EFI (ELECTRONIC PETROL INJECTION)	+	+	+	+	
> QASHQAI [2021] (J12)	CENTRAL CONSOLE	+		-		
	HYBRID CONTROL SYSTEM	+	+			
	KEYLESS SYSTEM	+	-			
	MOTOR GENERATOR	+	-	-		
	MULTIMEDIA SYSTEMS	+		-		
> X-TRAIL [2021] (T33)	ABS	+	+	+	+	
OPEL						
> ASTRA L [2021] (O5)	RADAR	+	+		+	
> CORSA E [2014- 2019]	EFI (ELECTRONIC PETROL INJECTION)	+	+	+	+	
> MOKKA [2012-2020] (J13)	EDI (ELECTRONIC DIESEL INJECTION)	+	+	+	+	
PEUGEOT						
> 308 [2021] (P5)	RADAR	+	+		+	
> RCZ [2010] (T75)	EDI (ELECTRONIC DIESEL INJECTION)	+	+	+	+	
PORSCHE						
> 911 [2011-2018] (991)	ADAPTIVE CRUISE CONTROL	+	+	+	+	
> BOXSTER [2012- 2015] (981)	ADAPTIVE CRUISE CONTROL	+	+	+	+	
. ,	CAMERA CONTROL MODULE	+	+	+	+	
> BOXSTER [2016] (982)	CAMERA CONTROL MODULE	+	+	+	+	
> CAYMAN [2013- 2016] (981)	ADAPTIVE CRUISE CONTROL	+	+	+	+	
	CAMERA CONTROL MODULE	+	+	+	+	
> CAYMAN [2016] (982)	CAMERA CONTROL MODULE	+	+	+	+	
> MACAN [2013] (95B)	DOORS SYSTEM	+	+	+	+	
	EFI (ELECTRONIC PETROL INJECTION)	+	+	+	+	
	FOUR WHEEL DRIVE (4WD)	+	+	+	+	
	LIGHTS SYSTEM	+	+	+	+	
	MULTIMEDIA SYSTEMS	+	+	+	+	

Model	System	Faults reading and erasure	Parameters and status reading	Activations	Adjustments	DoiP
PORSCHE						
> TAYCAN [2019] (Y1A)	CHARGER SYSTEM	+				
	COMFORT SYSTEM	+	+	+	+	
	DOORS SYSTEM	+	+	+	+	
	ELECTRIC VEHICLE WARNING SOUNDS	+	+	+	+	
	EMERGENCY CALL MODULE (E-CALL)	+				
	LIGHTS SYSTEM	+	+	+		
	MULTIMEDIA SYSTEMS	+				
	REAR STEERING AXLE	+	+		+	
	THERMAL MANAGEMENT	+	+	+	+	
SEAT						
> IBIZA [2017] (KJ)	STEERING LOCK	+				
> LEON [2012-2019] (5F)	STEERING LOCK	+				
> LEON [2020] (KL)	AUTOMATIC GEARBOX	+	+		+	
	EFI (ELECTRONIC PETROL INJECTION)	+	+	+	+	
	STEERING LOCK	+	_			
> TARRACO [2019] (KN)	STEERING LOCK	+				
SKODA						
> ENYAQ [2020] (NY)	BRAKE ASSIST	+	+			
	MOTOR GENERATOR	+	+	+	+	
	STEERING LOCK	+				
> FABIA [2021] (PJ)	STEERING LOCK	+				
> KAMIQ [2019]	STEERING LOCK	+				
> KAROQ [2017] (NU)	STEERING LOCK	+				
> OCTAVIA [2013-2019] (5E)	STEERING LOCK	+		-		
> OCTAVIA [2020] (NX)	STEERING LOCK	+				
> SCALA [2019]	STEERING LOCK	+				
> SUPERB [2015] (3V)	AUTOMATIC GEARBOX	+	+	+		
,	STEERING LOCK	+	_			
SUZUKI						
> SWIFT [2010-2017]	EFI (ELECTRONIC PETROL INJECTION)	+	+	+	+	
(AZG) TESLA	·					
> MODEL X [2015]	BATTERY CONTROL SYSTEM					
(5YJX)					+	
	BODY COMPUTER		_ _ +			
	ELECTRONIC PARKING BRAKE		+		+	
	TYRE PRESSURE MONITORING SYSTEM (TPMS)	+	+		+	

Model	System	Faults reading and erasure	Parameters and status reading	Activations	Adjustments	DoiP
TOYOTA						
> CAMRY [2017] (V7- VA7-VH7)	EFI (ELECTRONIC PETROL INJECTION)	+	+	+	+	
> HIGHLANDER [2019] (U7)	EFI (ELECTRONIC PETROL INJECTION)	+	+	+	+	
VAUXHALL						
> ASTRA L [2021] (O5)	RADAR	+	+	1	+	
> CORSA E [2014-2019]	EFI (ELECTRONIC PETROL INJECTION)	+	+	+	+	
VOLKSWAGEN		'				
> ARTEON [2017]	STEERING LOCK	+				
> CADDY V [2020] (SB)	ANTI-THEFT SYSTEM	+	_			
,	DOORS SYSTEM	+	+	+	+	
	EFI (ELECTRONIC PETROL INJECTION)	+	+	+	+	
	KEYLESS SYSTEM	+	+	+	+	
	STEERING LOCK	+				
> GOLF VII [2012-2019] (5G)	AUTOMATIC GEARBOX	+	+	+		
	STEERING LOCK	+				
> GOLF VIII [2020] (CD)	AUTOMATIC GEARBOX	+	+		+	
	EFI (ELECTRONIC PETROL INJECTION)	+	+	+	+	
> ID.3 [2020] (E1)	ANTI-THEFT SYSTEM	+				
	KEYLESS SYSTEM	+	+	+	+	
	MOTOR GENERATOR	+	+	+	+	
	STEERING LOCK	+				
> ID.4 [2020] (E21)	ANTI-THEFT SYSTEM	+				
	MOTOR GENERATOR	+	+	+	+	
	STEERING LOCK	+	_,			
> ID.5 [2021] (E39)	ABS	+	+			
	AIR CONDITIONING	+	+	+	+	
	ANTI-THEFT SYSTEM	+		- ·		
	BATTERY PACK	+	+	+	+	
	BRAKE ASSIST	+	+			
	CENTRAL GATEWAY	+	+	+	+	
	DCDC CONVERTER	+	+	+	+	
	DOORS SYSTEM	+	+	+	+	
	ELECTRIC VEHICLE WARNING SOUNDS	+	+	+	+	
	ELECTRONIC CENTRAL ELECTRICS SYSTEM	_ +	+	+	+	
	KEYLESS SYSTEM	+	+	+	+	
	LIGHTS SYSTEM	+	+	+		
	MULTIMEDIA SYSTEMS	+	+			

Model	System	Faults reading and erasure	Parameters and status reading	Activations	Adjustments	DoiP
VOLKSWAGEN						
> ID.5 [2021] (E39))	PARKING ASSISTANCE SYSTEM	+	+	+	+	
	PLUG-IN CONNECTOR	+	+	+	+	
	POWERSTEERING	+	+		+	
	SRS (AIRBAG)	+	+			
	STEERING CONTROL UNIT	+	+	+	+	
	STEERING LOCK	+				
> ID.BUZZ [2022] (EB)	BRAKE ASSIST	+	+	-		
> PASSAT [2014] (3G)	AUTOMATIC GEARBOX	+	+	+		
	STEERING LOCK	+		-		
> POLO [2018] (AW)	STEERING LOCK	+				
> TAIGO [2021] (CS)	STEERING LOCK	+				
> T-CROSS [2019] (C11)	STEERING LOCK	+				
> TOUAREG [2017] (CR)	STEERING LOCK	+		-		
> T-ROC [2017] (A1-D1)	STEERING LOCK	+				
VOLVO		,				
> S60 [2010-2018] (134)	EDI (ELECTRONIC DIESEL INJECTION)	+	+	+	+	
> S60 [2018] (224)	EFI (ELECTRONIC PETROL INJECTION)	+	+	+	+	
> S90 [2016] (234)	EFI (ELECTRONIC PETROL INJECTION)	+	+	+	+	
> V60 [2010-2018] (155, 157)	EDI (ELECTRONIC DIESEL INJECTION)	+	+	+	+	
> V60 [2018] (225, 227)	EDI (ELECTRONIC DIESEL INJECTION)	+	+	+	+	
	EFI (ELECTRONIC PETROL INJECTION)	+	+	+	+	
> V90 [2016] (235, 236)	EDI (ELECTRONIC DIESEL INJECTION)	+	+	+	+	
	EFI (ELECTRONIC PETROL INJECTION)	+	+	+	+	
> XC40 [2017] (536)	EFI (ELECTRONIC PETROL INJECTION)	+	+	+	+	
> XC60 [2008-2017] (156)	EDI (ELECTRONIC DIESEL INJECTION)	+	+	+	+	
> XC60 [2017] (246)	EDI (ELECTRONIC DIESEL INJECTION)	+	+	+	+	
	EFI (ELECTRONIC PETROL INJECTION)	+	+	+	+	
> XC90 [2014] (256)	EFI (ELECTRONIC PETROL INJECTION)	+	+	+	+	